

# TR 360

|                     |                                       |
|---------------------|---------------------------------------|
| <b>TIRE SIZE</b>    | <b>18X7 - 8</b>                       |
| <b>UM</b>           | US STANDARD                           |
| <b>CONSTRUCTION</b> | ⊠ BIAS                                |
| <b>MACHINERY</b>    | ATTREZZI AGRICOLI / ATTREZZI AGRICOLI |
| <b>VERSIONE</b>     | STANDARD                              |
| <b>TIRE TYPE</b>    | TL                                    |



## DIMENSIONI US STANDARD

|                   |          |                |                |
|-------------------|----------|----------------|----------------|
| <b>CODICE USA</b> | 94013104 | <b>RC (IN)</b> | 52.5           |
| <b>SW (IN)</b>    | 7.1      | <b>RIM REC</b> | 5.5            |
| <b>OD (IN)</b>    | 18.1     | <b>ECE</b>     | E4-106R-002184 |
| <b>SLR (IN)</b>   | 8.0      | <b>PR</b>      | 6              |

## LOAD CAPACITY (LBS/TIRE)

|                  |           |
|------------------|-----------|
| <b>MPH / PSI</b> | <b>46</b> |
| 10               | 990       |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.