

# AGRIMAX RT 955

<b>TIRE SIZE</b>	230/95 R 42
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	133 A8/B



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	228	<b>RIM REC</b>	W 7
<b>OD (MM)</b>	1506	<b>RIM ALT</b>	W 8
<b>SLR (MM)</b>	714	<b>ECE</b>	E4-106R-000772
<b>RC (MM)</b>	4595	<b>SRI</b>	725

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	805	1055	1280	1405	1485	1630	1775	1920	2060	-
40	805	1055	1280	1405	1485	1630	1775	1920	2060	-
30	860	1125	1370	1500	1590	1745	1900	2055	2205	-
10	960	1210	1485	1765	2040	2105	2350	2600	2845	3090

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.