


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>300/95 R 46</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	148 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	295	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1738	<b>RIM ALT</b>	W 10; W 11; DW 10; DW 11
<b>SLR (MM)</b>	812	<b>ECE</b>	E4-106R-000790
<b>RC (MM)</b>	5318	<b>SRI</b>	825

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	1105	1295	1485	1670	1860	2020	2205	2365	2585	2805	2995	3150	-
40	1105	1295	1485	1670	1860	2020	2205	2365	2585	2805	2995	3150	-
30	1185	1385	1590	1790	1995	2160	2365	2535	2770	3005	3210	3375	-
20	1360	1590	1825	2055	2290	2480	2715	2910	3180	3450	3685	3875	-
10	1525	1785	2045	2310	2570	2785	3045	3265	3570	3875	4135	4350	4725

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.