

AGRIMAX RT 955

| | |
|---------------------|--|
| TIRE SIZE | 270/95 R 46 |
| UM | US STANDARD |
| CONSTRUCTION | |
| MACHINERY | SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS |
| VERSION | STANDARD |
| TL/TT | TL |
| LI/SS | 143 A8/B |



DIMENSIONS US STANDARD

| | | | |
|-----------------|----------|----------------|----------------|
| USA CODE | 94042555 | RC (IN) | 203.5 |
| SW (IN) | 10.8 | RIM REC | W 9 |
| OD (IN) | 66.3 | RIM ALT | W 8 ; W 10 |
| SLR (IN) | 31.2 | ECE | E4-106R-000785 |

LOAD CAPACITY (LBS/TIRE)

| MPH / PSI | 12 | 17 | 23 | 29 | 35 | 41 | 46 | 52 | 58 | 64 |
|-----------|------|------|------|------|------|------|------|------|------|------|
| 30 | 2470 | 3190 | 3850 | 4210 | 4510 | 4930 | 5360 | 5710 | 6000 | - |
| 25 | 2470 | 3190 | 3850 | 4210 | 4510 | 4930 | 5360 | 5710 | 6000 | - |
| 20 | 2650 | 3420 | 4120 | 4510 | 4830 | 5280 | 5730 | 6120 | 6440 | - |
| 5 | 3410 | 4410 | 5310 | 5820 | 6230 | 6810 | 7400 | 7890 | 8300 | 9020 |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.