

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>420/85 R 34</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	142 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	438	<b>RIM REC</b>	W 15 L
<b>OD (MM)</b>	1578	<b>RIM ALT</b>	W 13 ; W 14 L
<b>SLR (MM)</b>	709	<b>ECE</b>	E4-106R-000656
<b>RC (MM)</b>	4702	<b>SRI</b>	750

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6
50	1460	1700	1935	2175	2415	2650
40	1460	1700	1935	2175	2415	2650
30	1565	1820	2075	2330	2585	2840
10 LT	1960	2280	2600	2920	3240	3555
10 HT	1565	1820	2075	2330	2585	2840

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.