

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>340/85 R 28</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	127 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	353	<b>RIM REC</b>	W 12
<b>OD (MM)</b>	1289	<b>RIM ALT</b>	W 11
<b>SLR (MM)</b>	588	<b>ECE</b>	E4-106R-000593
<b>RC (MM)</b>	3890	<b>SRI</b>	625

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6
50	965	1120	1280	1435	1595	1750
40	965	1120	1280	1435	1595	1750
30	1035	1200	1370	1540	1710	1875
10 LT	1290	1505	1715	1925	2135	2345
10 HT	1035	1200	1370	1540	1710	1875

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.