

MODEL:998D

User Manual




Welcome to the pet trainer manual

- The manual including all the details of the dog trainer .
- The latest instructions of the dog trainer
- The features and main functions of the dog trainer
- How to test the dog trainer

General tips

- Eliminate one misbehavior or teach one obedience command at a time.
If you move too fast with the training, your pet may become confused
- Be consistent. Give your pet a tone or stimulation with each misbehavior
- Do not over-correct your pet. Use as few stimulation as possible to train your pet
- Unless you can supervise him, it is recommended that you restrict your pet from situations in which he has a history of misbehaving. However , setting up a situation as a training session can dramatically improve your chances of success
- If your pet reacts to the training by hiding or acting fearful, redirect his attention to a simple and appropriate behavior such as the "Sit" command

Key definition



1. Antenna
 2. Led light
 3. Indication light
 4. LCD Display
- 000 1-100 level
- ⚡ Static shock mode
 - 🔊 Vibration mode
 - 🔊 Beep mode
 - 💡 Light mode
- 1 Channel 1
 - 2 Channel 2
- 🔋 Battery exhaustion
5. Up/down button
 6. Led light button
 7. Channel button
 8. Launch button
 9. Mode button

Features


1. 100 levels of vibration.
 2. 100 levels of static (optional).
 3. The levels can be altered by use of up & down button.
 4. A lone button activates a tone on the receiver.
 5. The system can be used for 1 or 2 receivers.
- POWER SAVING
6. The receiver will turn off if it is unused for 4 minutes.
 7. Any Movement will activate the receiver into STAND BY MODE.
 8. The transmitter will go into TAND BY MODE if there is no operation after 20 seconds and turn off after 2 minutes.

Notes for use:


1. The lifetime of the batteries vary according as how often you use the product therefore you should often check the batteries by watching the indicator light in the receiver and the indicator sign on the LCD screen of the transmitter.
2. The valid distane of remote control means the straight-line dittance between the transmitter and the receive without obstacles in between, If there are interference signal sreening around, the actual remote control distance may vary.
3. This product is for pet training. Only by training, the pet can understand the intention of its owner. Good effect can only be achieved after a period of training.
4. Training sessions should be kept positive and short, about 10-10 minutes long each time.
5. Presently, this product is the most affective and safest tool for training pet. Following the correct operational instructions, you can effectively train the pet and bring it no harm.

How to match

- 1: Please install the batteries into the remote first. The remote will be turned on automatically (please note that the remote will be turned off after 20 seconds, Then you can press the Mode button to restart the item.).



2: Install the batteries into the receiver, you can hear a sound "beep", and immediately, Press Y button of the remote within 5 seconds. Then you will hear a "beep" again, that means the item is paired successfully. If not, please try the above steps.



After install the batteries of receiver, you will hear a sound "beep", now press Y button of remote within 5 seconds, you can hear a "beep" again that means paired successfully. If not, please release the batteries of receiver and install them once again, and try the above steps.

Note : How to pair the 2nd receiver : Please press the "1/2" button of the remote transmitter, choose the 2nd channel, install batteries of the 2nd receiver collar. you can hear a sound "beep", and immediately, Press Y button of the remote within 5 seconds. Then you will hear a "beep" again, that means the receiver is paired successfully. If the receiver does not "beep", please repeat this step.

3: Press the "MODE" button to choose different models. You can adjust the intensity from 001 to 100 by the UP/DOWN button at the right side of the remote, then press the "Y" button to finish the installation. Please note that the 1/2 button can change the channel to channel one or channel two.



Test Static Shock Function

- Take out the test bulb from the package and wind its metal wire on the Receiver collar's contact points
- Press Mode button of Remote transmitter, switch to Shock Mode, confirm LCD display not to be 0, you can press UP/DOWN button on the right side to adjust
- Press Y button, test bulb will flash, that means Shock function works



Test Vibration Function

- Press Mode button of Remote transmitter, switch to Vibrate Mode, confirm LCD display not to be 0, you can press UP/DOWN button on right side to adjust
- Press Y button, Receiver collar will vibrate, that means Vibration function works



Test Beep Function

- Press Mode button of Remote, switch to Beep Mode
- Press Y button, Receiver collar will beep, that means Beep Function works



Test LED Light Function

- Press Mode button of Remote Transmitter, switch to LED light Mode
- Press Y button, Receiver Collar will flash, that means LED Light Function works

How to Test Static Shock Function (after encoding is completed)

1. Take out the test bulb from the package and put it on the Receiver collar's contact points




2. Press Mode button of Remote transmitter, switch to Shock Mode, confirm LCD display not to be 0, you can press UP/DOWN button on the right side to adjust




Shock Mode

3. Press Y button, test bulb will flash, that means Shock function works





Put the collar belt in receiver

Fold the collar belt fine, stuffed it into the clip slot of receiver and smooth it hardly.



install the receiver's contact column

According to the size of the dog and dog hair length, choose the right column for your dog between the tall one and short one.



Hints to fast results using a Remote Trainer

1. Condition your dog to the remote collar, or electronic collar, by allowing him to wear it while doing something he enjoys instead of only putting it on directly before training. Also, keep the transmitter with you even when you are not training. This will help prevent him from associating the stimulation he receives to the collar or the transmitter.
2. Since the stimulation (sometimes incorrectly called a shock) from the remote collar, or electronic collar, is Non-directional, always use it with a long - line or leash and away from people and other animals. Assisting your dog with a leash will also help him learn faster. Do not use the remote collar without a leash or long line until your dog is fully trained.
3. Always use the lowest stimulation level from the remote collar, or electronic collar, as possible for dog. When choosing the right level of stimulation, begin at level one. If your dog shows no reaction (turns head, scratches at collar, flicks ears, etc.), go up one level until you find the proper level. Your dog should not vocalize or panic during the stimulation. If this happens, the stimulation level is too high.
4. Never use the remote collar, or electronic collar, to correct or eliminate any form of aggression or biting behavior. In the event your dog is exhibiting such aggressive behaviors, contact a qualified professional trainer in your area.
5. Start with behaviors your dog already understands do not use the remote collar, or electronic collar, to reinforce commands that have not yet been covered. If your dog gets confused, help him with the leash and plenty of praise. When reinforcing a command with a correction, it is critical that you do so without emotion, then immediately praise and reward your dog for making the right decision.
6. Training in new locations may cause your dog to become distracted. Causing you to reinforce your commands with the remote collar, or electronic collar, more often as a result. The level of stimulation may also need to be adjusted up or down, depending on the exercise or distraction up or down, depending on the exercise or distraction level. It is important that you use a leash or long - line to help your dog perform his commands in new locations.

Training sessions should be kept positive and short, about 10-15 minutes long, so your dog will focus his attention on you. Look for all positive changes in your dog's behavior and be sure to reinforce them with plenty of praise. Remember to always end your training session on a high note. Stop training and play with your dog as soon as he has accomplished a new level of proficiency.

Frequency: 433.825MHz
Transmitter: 2x4LR44/6V
Receiver: 2xAAA/1.5V



Note: Please take out the batteries if you don't use it for a long time.