

# Universal User Manual Smart Plug/Lamp holder/Switch/Controller





## Works with Amazon Alexa and Google Assistant

Thank you for choosing our Wi-Fi smart products. This smart product can connect 2.46 Wi-Fi. No matter where you are, as long as there is a network, you can control your devices via smart phone App. The products have timer function and appointment function.

Please read the manual before usage.

#### Identification of parts:



#### Specification

Power supply: AC100V-240V, 50/60Hz Load current: 10A Resistive Max WIFI standard: 2.4G 802.11 b/g/n Operation temperature:-20°C ~+50°C

#### peration:

Down load APP:
You can scan the OR code to down load:



You also can search "Smart Life " in App Store or Google Play to install the App.



## 2. Register App:

>>Run the APP
>>Login with your account & password.

For the first time using, you have to register a new account.

## 3. APP configuration:


Please make sure the smart product and your mobile phone connect to the same 2.4G Wifi router.

A. Easy mode:

>>Long press the reset button (If several buttons, long press any button) over 5 seconds until indicator rapidily blink. If not, try it again. (2 times per second).

>>Open the APP and click "Add Device" or "+" to add device, select "Electrical outlet" in the list of devices. (can chose it for all Wi-Fi product.) >>Click the "Confirm indicator rapidly Blink", search Wif router and type in password and click "Confirm".





#### B. AP Mode:

 AP mode:
 Hold the button 5 seconds until indicator light is slowly flashing.

If not, try again. (1 times every 3S).
>>Click the "AP Mode", then click

"Confirm indicator slowly blink". Search WIFI
router and type in password and click "Confirm".
>>Click "Connect now", connect to the WIFI
"SmartLife-XXXX". Then, back to the APP.
>>Once the configuration is completed, the
indicator light will stop flickering.

 Timer & Appointment function: Click to set ON/O ime.

7. Others: Click ".." and you will see:

- Manual control: Click the button to control the ON/OFF status.
- 6. Restore Manufacturer Defaults If you need to restore manufacturer defaults, please hold the butten over 5 seconds until indicator flashing quickly. If not, try again.
- "Modify Device Name"
  "Device Sharing", "Check for Firmware Update"
  "Remove device", "Restore Manufacturer Defaults"

# How to sync With Amazon Echo 1. Link Smart life account to Echo

>>Go to Home menu on Alexa App.
>>Select "Skills" in Home menu, search.
"Smart Life" on search window select "Smart

"Smart Life" on search window.select "Smart Life and tap

"Enable" to enable the Smart Life skill.
>>In link page, type in your Smart Life account & assword and tap "link now" to link your Smart life account. Wait until "Alexa has been successfully inked with Smart Life" shows up.

2. Control smart devices through Echo



>>Echo needs to discover your smart devices before it controls them. You can say "Alexa, discover devices" to Echo. Echo will discover devices in about 20 seconds

Now, you can control your smart devices through Echo: "Alexa, turn on/offi bedroom light" >>If you changed the device's name on Smart Life APP, Echo must re-discover it before you control them.


>>You can set up groups on Alexa App to control.

4

# User Manual 1CH/2CH/4CH Smart Breaker







# Parameter

Wi-Fi standard: 2.4GHz b/g/n Input voltage: 100-240V AC Output voltage: 100-240V AC Max. load: 240V 10A/CH Max. total load: 240V 10A/ICH, 10A/2CH, 16A/4CH.



1) Start with "Smart Life"App.




- ② Register an Smart Life Smart account.
- ③ IF you have Smart Life account, just log in.



(4) Wiring instructions:


ON/OFF operating principle: The connected appliances work/stop through live wire power on/off.


\*Note: The WiFi Switch must be powered up by N and L




4.1 N+L 2-Wire connection:

(Earth wire is not essential for 4CH, example: lamp/fan)







4.2 N+L+E 3-Wire connection: ((Earth wire is not needed for 4CH, example: refrigerator/heater)



⑤ Press one of the buttons for 7s until the WiFi LED blinks like this: blinks 3 times and on repeatedly.







Max Red AC 1107 10A 1000W AC 2257 10A 2000W

- page.

  The Please make sure the flashes (2 times per
- second), tap to go on to the next step.
- ® Input your WiFi password.
- Name your device.
- When the WiFi LED is on, the device is online. Start to control now!

6

9