CONTROL BOTTOM

RESET

POWER

MIC

LED

3.5 mm AUDIO OUT

MICRO USB CHARING ONLY

- Please charging 3hours as first t me use

▨ PAIR NG

1. Press "Power" bottom around 3Sec until LED Light Up(Blue)
2. Press "Power" Bottom about 4 sec unti LED ight up (Slow F ashing) then the device nto Paring Mode now
3. Go to Phone/Pad/PC/NB setting to make sure the Bluetooth is turn on and searching for "Jungle Beats" then connected.
4. When device in connection mode, the LED will continue on.

▨ STANDBY

- When device disconnect over 2 min then "Jung e Beats" will entry "Standby Mode" automatica ly.

▨ LINK BACK

- Long-press "Control" bottom unti LED l ght up (Fast Flashing) then device wi l auto searching connected device

▨ CONTROL FUNCTION

- The "Control" bottom a lows changing the existing status of the device. When short press the "Contro " bottom, it can be "P ay","Pause/Stop","Answer a Ca l", "End a Call"

- "Reject a Call" needs to LONG-PRESS the contro bottom!!

▨ LED NDICATE

- Low Battery　Red Flashing
- Charging – Red
- Paring　Blue Slow Flash ng
- Searching for connected device – Blue Fast Flashing
- Connected　Blue

Function	Power	Control	LED Status
Power On / Off	Press 3 sec		Flashing (B ue+Red)
Searching for linked devices			Fast Flashing (B ue)
Pairing Mode	Press 4 sec		Slow Flash ng (Blue)
Pairing Done			B ue Steady
Link Back		Long press	Flashing (Blue)
Standby Mode			Both Light down
play / pause		Short press	B ue Steady
Answer Call / End a Call		Short press	
Reject Ca l		Long press	
Low battary			Flashing (Red)
Charing Mode			Red Steady

- Press "Reset" Key w l back to default setting

- 3 5mm to 3.5mm cable

- Micro USB Charging cable

- 3.5mm to RCA cable (Opt on)