- 1. Press the "SAMPLE" add turn on the machine at the same time, three display window all shows "0".
- 2. Press "6" and "8" at the same time, then press "INPUT CLEAR".
- 3. Enter 5 numbers according to your capacity and divisions.

Capacity	Division	Enter the number
3kg	0.2g	10312
3kg	0.1g	11312
3kg	0.05g	12312
6kg	0.5g	20312
6kg	0.2g	21312
6kg	0.1g	22312

- 4. Press "SAMPLE", when there is a "Di Di Di" sound, turn off the machine.
- 5. Press the "SAMPLE" add turn on the machine at the same time, three display window all shows "0".
- 6. Press "9".

"ADD"

7. If you need manual 3kg, you need prepare 3 piece of 1kg weight.

When the "STABLE" light comes on, "Weight" window shows "0L", press "ADD" When the "STABLE" light comes on, "Weight" window shows "1L", put a 1kg weight press

When the "STABLE" light comes on, "Weight" window shows "2L", put another 1kg weight press "ADD"

When the "STABLE" light comes on, "Weight" window shows "3L", put another 1kg weight press "ADD" twice.

8. Take the weight off, the calibration is completed.

