

Calibration Manual



1 - Set the range and division. Press "SAMPLE" to turn on the scale, enter the modification interface, press "6" and "8" numeric keys at the same time, press "INPUT CLEAR" to clear the number, 3KG/0.1g to enter "11312"; 6KG/0.2g to enter "21312"; 15KG/1g to enter "30312"; 30KG/1g to enter "41312" after the modification is completed, press "SAMPLE" to enter the next step and then shut down.

2 - The second step is to press "SAMPLE" to turn on the scale, enter the modification interface, press the digital key "9" to enter three segment linear calibration. When the weight bar shows "0L", press "ADD" to enter "1L", and then put on the balance of 1/3 weight of the full weight capacity. After the value of unit price column is stabilized, press "ADD" to enter "2L", then put on the balance of 2/3 weight of the full weight capacity. After the value of unit price column is stabilized, press "ADD" to enter "3L", and put on a balance of 100% weight of the scale weight capacity. After the value is stabilized, press "ADD", then finish calibration.