


SHOOTING TENTS INSTALLATION DESCRIPTION




1. Attach the three way adapter interface to the support rod.



2. Let the fixed tee and support rod become a rectangle.




3. Use one way adapter let 2 nozzle studes become the longest support rod.



4. Make it became cuboid use three way adapter and support rod.



5. Make the Hanger rod har in the middle use the 2pcs Hook.



6. Spread the shooting tents cloth then put it on the cuboid shelf.



7. Close the side zipper.



8. Use the velcro closed sides of shooting tents's front.



9. Put the clip to the topside support rod of the shed cloth's inside.



10. There is magnet in the bottom of lamp board, it can stick on the support rod.



11. Take the power line out from shooting tents cloth's front hole.



12. Connect the power line of the lamp board to the power drive.