



Notes:

If Installing like Number 1 and 3, it will be stable, flexible and free of noise during application. If Installing like Number 2 and 4, there will be noise when opening and closing the door during allication. If screw is not tightened, the door will sway during application.



Installation finished, the closing speed is regulated by speed control hole (needle), left for quick and right for slow. Speed regulation unfinished, it is forbidden to push or pull the door to prevent door and floor spring damage.

After regulating the sites of floor prings, tighten the screw nuts to fix the floor springs, or it will sway during application.



www.cablematic.com