



PIN 2	J1850 Bus+
PIN 4	Chassis Ground
PIN 5	Signal Ground
PIN 6	CAN High (J-2284)
PIN 7	ISO 9141-2 K Line
PIN 10	J1850 Bus
PIN 14	CAN Low (J-2284)
PIN 15	ISO 9141-2 L Line
PIN 16	Battery Power