


BACK VIEW


BUY ON
www.cablematic.com



OH51

Item	Spare parts	Q'ty
1	FIXED TUBE	1
2	PLASTIC COVER	2
3	LEFT BOTTOM TUBE	1
4	SCREW CAP 5/16"-18UNC*L3/4" + 2 WASHERS	20
5	WHEEL	4
6	CIRCULAR PLASTIC COVER Ø 50.8	4
7	RIGHT BOTTOM TUBE	1
8	SCREW RH 1/4"-20UNC* L3"	4
9	FIXED PLATE	4
10	PLASTIC TOP Ø 1"	8
11	ANGLE ADJUSTMENT GROUP	2
12	SQUARE PLASTIC COVER □ 45*45	2

BUY ON
www.cablematic.com



A	ALLEN WRENCH NO.6	1
B-1	SCREW M4*L35 FOR PDP	8
B-2	SCREW M5*L35 FOR PDP	8
B-3	SCREW M6*L35 FOR PDP	8
B-4	SCREW M8*L35 FOR PDP	8
C-1	SCREW M4*L12 FOR LCD	8
C-2	SCREW M5*L15 FOR LCD	8
C-3	SCREW M6*L15 FOR LCD	8
C-4	SCREW M8*L15 FOR LCD	8
D-1	WASHER $\varnothing 6 * \varnothing 18$ FOR PDP	8
D-2	WASHER $\varnothing 8 * \varnothing 18$ FOR PDP	8
E-1	SPRING WASHER $\varnothing 4$ FOR PDP	8
E-2	SPRING WASHER $\varnothing 5$ FOR PDP	8
E-3	SPRING WASHER $\varnothing 6$ FOR PDP	8
E-4	SPRING WASHER $\varnothing 8$ FOR PDP	8
F	SLEEVE $\varnothing 8.5 * \varnothing 20 * L12.5$	8