


BUY ON
www.cablematic.com

OH52

Item	Spare parts	Q'ty
1	RIGHT FIXED TUBE	1
2	LEFT FIXED TUBE	1
3	ANGLE ADJUSTMENT GROUP	1
4	BASE TUBE	2
5	WHEEL	4
6	PLASTIC COVER \varnothing 25.4	4
7	PLASTIC COVER \varnothing 50.8	4
8	SCREW CAP 5/16" -18UNC* L3/4" +2WASHERS	12
9	PLASTIC COVER \square 45*45	2
10	CIRCULAR TUBE	2
11	SCREW BH 5/16"-18UNC *L3"	8
12	WASHER \varnothing 5/16"	8
13	SPRING WASHER \varnothing 5/16"	8
14	FIXED PLATE	4
15	SCREW RH 1/4"-20UNC*L3"	4
16	SQUARE TUBE	2
17	ALLEN WRENCH NO.6	1
18	WRENCH NO.21	1

BUY ON
www.cablematic.com



A-1	SCREW M4*L35 FOR PDP	8
A-2	SCREW M5*L35 FOR PDP	8
A-3	SCREW M6*L35 FOR PDP	8
A-4	SCREW M8*L35 FOR PDP	8
B-1	SCREW M4*L12 FOR LCD	8
B-2	SCREW M5*L15 FOR LCD	8
B-3	SCREW M6*L15 FOR LCD	8
B-4	SCREW M8*L15 FOR LCD	8
C-1	WASHER $\varnothing 6^* \varnothing 18$ FOR PDP	8
C-2	WASHER $\varnothing 8^* \varnothing 18$ FOR PDP	8
D-1	SPRING WASHER $\varnothing 4$ FOR PDP	8
D-2	SPRING WASHER $\varnothing 5$ FOR PDP	8
D-3	SPRING WASHER $\varnothing 6$ FOR PDP	8
D-4	SPRING WASHER $\varnothing 8$ FOR PDP	8
E	SLEEVE $\varnothing 8.5^* \varnothing 15^* L20mm$ FOR PDP	8