


ML5072

INSTRUCTIONS

BUY ON
www.cablematic.com




WARNING!


Severe personal injury and property damage can result from improper installation or assembly. Read the following warning carefully before beginning.

- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing, if you require replacement parts, please contact your local distributor for assistance.
- This product fits most 32"-65" LCD/plasma screen; maximum weight of LCD/plasma screen: 165 lbs/75KG; AV shelf max load: 10 lbs/4.5kg.
- Do not use this product for anything other than the original design.
- This product contains moving parts, please use with caution.


Accessories :




Screw package list For Tv Set Mounting :




Screw package list for TV Stand Mounting:




1. Installation of base and castors




2. Installation of upper tray and upper tray connecting rod




3.installation of column,base and eight clip




4.Installation of Lower tray




7.Installation of TV and vertical pole




8.Installation of TV sets and stand




5.Installation of panel




9.Protection of TV and mobile rack



10.Arrangement of power line



6.Connection of the upper tray and Inner tube fixing plate



11.Technical parameters

