
www.cablematic.com



M4 x L12mm

Fig 1. Warming on Brake Screws




Fig 3. To change monitor orientation (Portrait / Landscape)

0





Fig 2. To adjust the tilting angle (of the monitor)



Use a flat-pin screw-driver to push open the plastic cap.

in Loosen the cap screw by Allen wrench NO.6 adjust the tilting angle then tighten the cap screw again.

Fig 4. Burglar-proof and Quick release

