


Item	Spare parts	Q'ty
1	WALL BRACKET	1
2	EXTENSION SUPPORT	2
3	EXTENSION SUPPORT	2
4	HANG BOX	2
5	FIXED TUBE	2
6	ANGLE ADJUSTMENT GROUP	1
7	FIXED PLATE	2
8	EXTENSION PLATE	4
9	SCREW CAP 5/16"-18UNC*L3/4" WITH 2 WASHERS	8
10	NYLON NUT 3/8"-16UNC	6
11	SCREW BH 3/8"-16UNC*L58mm	6
12	SCREW RH 1/4"-20UNC*L3"	2
13	PLASTIC TOP COVER $\phi$ 1"	4
14	ALLEN WRENCH NO.6	1
15	NUT 1/4"-20UNC	16
16	SCREW BH 1/4"-20UNC*L1/2"	16

BUY ON

[www.cablematic.com](http://www.cablematic.com)



A-1	SCREW M4*L35 FOR PDP	4
A-2	SCREW M5*L35 FOR PDP	4
A-3	SCREW M6*L35 FOR PDP	4
A-4	SCREW M8*L35 FOR PDP	4
B-1	SCREW M4*L12 FOR LCD	4
B-2	SCREW M5*L15 FOR LCD	4
B-3	SCREW M6*L15 FOR LCD	4
B-4	SCREW M8*L15 FOR LCD	4
C-1	WASHER $\phi$ 6* $\phi$ 16 FOR PDP	4
C-2	WASHER $\phi$ 8* $\phi$ 16 FOR PDP	4
D-1	SPRING WASHER $\phi$ 4 FOR PDP	4
D-2	SPRING WASHER $\phi$ 5 FOR PDP	4
D-3	SPRING WASHER $\phi$ 6 FOR PDP	4
D-4	SPRING WASHER $\phi$ 8 FOR PDP	4
E	SLEEVE $\phi$ 8.5* $\phi$ 15*L20mm FOR PDP	4