


Instruction Manual

Note: We recommend that this product is installed by the professional only. we accept no liability for damages caused by incorrect assembly, installation or use, if there is any doubt, please contact the specialist from the seller for help.









Important:

1. For safety reasons, the wall or mounting surface must be capable of supporting the combined weight of the mount and the display. otherwise the structure must be reinforced.
2. Safety gear and proper tools must be used. Failure to do so can result in property damage or serious injury.
3. Make sure that no electrical cables, water pipes or gas pipes are located within the wall.





BUY ON
www.cablematic.com

Tool list


| | | | | | | | | | | | |
|------------|--|-----------|------------|--|-----------|------------|--|-----------|------------|--|-----------|
| W-B |  Φ10x50 concrete anchor | X2 | M-B |  M5x16 screw | X4 | M-F |  wrench | X1 | M-H |  5mm allen key | X1 |
| W-C |  Φ 5x10x1 spacer | X4 | W-A |  M5.5x50 self tapping screw | X2 | M-G |  wire button | X2 | M-B |  M4x10 screw | X4 |

Installing the wall mount.

1. Put the wall mount onto the wall with screws. make sure the three holes are on the same line.



2. Use the right spacer and screw to fix the display on the mount.



3. Adjust display with bolt. fix the bolt after you adjust display to the right position.