

DC 12V Power Supply

1. Mount the enclosure in a pre-selected location where it is out of sight and protected from moisture and water.
2. Knock out the appropriate knock-outs for running cables.
3. Turn power switch to "OFF" position.
4. Connect all camera's power pairs to individual protected outputs.
5. Plug the AC plug into AC100-240V outlet. Turn power switch to "ON" position, the green light should be on.
6. Close the cover and secure it with the provided screws.
7. The individual PTC fuse is rated be on 60V/2.5A(4 outputs-5A, 9 outputs-10A); 60V/1.1A(9 outputs-5A, 18 outputs-10A).
8. The PTC5 and PTC10 fuse is rated at 16V/14A(4 outputs-5A, 9 outputs-5A, 9 outputs-10A); The PTC19 and PTC20 fuse is rated at 30V/6A(18 outputs-10A). The PTC19 and PTC20 fuse is rated at 16V/14A(18 outputs-15A).

