

# Peak Fire Sound Pick-up User Manual

BUY ON  
[www.cablematic.com](http://www.cablematic.com)

一、 Peak Fire Sound Pick-up adapt 3 wire system or "3P" connection terminal

1、 3 wire ↔ 3P connection terminal

Red ↔ V V+ : DC 12V+

White ↔ S, SIG : Audion signal +

Black ↔ G, GND : Public (Power + & Audion signal -)

2、 Smoke type 1. DC 12V+ 2--3 Public 4. Audio +

二、 PeakFire Power Adaptor (PR-100 / PA-100)

1 ↔ NC1 : Alarm out 1 (Close)

2 ↔ NC2 : Alarm out 2 (Close)

3 ↔ 1 GND/ COM----GND : Audiosignal - ( Out )

4 ↔ 2 AUDIO OUT : Audio signal + ( Out )

5 ↔ 3 GND/COM----GND : Public(power & audion signal -)

6 ↔ 4 AUDIO IN : Audio + ( In )

7 ↔ 5 VDD 12V : DC 12V + ( In )

## Remark :

- 1、 To monitor by connecting 3.5 earphone to Front-panel.
- 2、 Clockwise to increase the audio out signal, anticlockwise to decrease the audio out signal.
- 3、 Clockwise to increase the sensitivity, anticlockwise to decrease the sensitivity with the potentiometer in the lower right corner.

Website: [WWW.peakfire.com](http://WWW.peakfire.com) Hotline: 4000-113-553

