



# USER MANUAL

Thank you for having chosen our  
For your own safety, please read the user manual carefully before installing it.

## SPECIFICATIONS TECHNIQUES

Power Supply	<b>Input AC110V-240V~50/60Hz, 1.5A</b> <b>Output DC12V 2.5A</b>
Power Consumption	36W
Rotation Speed	0.5RPM-2RPM
Max. Loading Weight	100KG
Product Dimensions	Dia60cm, H8cm
Net Weight	7.9kg/pc

Manual control:



## Instruction

1. Place the turntable horizontally;
2. Plug in the power cord;
3. Approach IR remote control to the turntable within 5m by aiming it at the infrared receiver on turntable ;
4. Press direction button "CW" to rotate clockwise, or press "CCW" to rotate counterclockwise(Same in remote control and Manual button control).
5. Press "+" to speed up ,and press "-" to speed down(Same in remote control and Manual button control).
6. Keep the turntable away from water.
7. keep the turntable out of reach of children under 3 years .

Remarks: each time to change rotating direction by remote control ,it takes 2 seconds for the turntable to receive the command and respond