


Photography Turntable ND-P2807

I. Code Introduction



①: Photography Turntable

②: DC12V adapter

③: Remote control

④: Signal cable

⑤: Shutter release connectors

1: Display Screen

2: Signal port

3: On/Off Switch

4: Power supply

A: Rotation degree adjustment

B: Rotation degree digital

C: Remote signal sensor

D: Manual connection

E: Time Digital

F: Time adjustment

II. Product Description

Size: Dia28cm, H7cm;

Loading capacity: Around 30KG

Voltage: DC12V

III. Link method / Operation

1. Place the turntable at a horizontal position.
2. Connect ② to 4 for power supply.
3. Connect ④ to 2, and select a right shutter release connector for your DSL, then connect ⑤ to ④, and plug ⑤ to DSL.
4. Manually adjust DSL focus for perfect picture.
5. Turn on the turntable switch.
6. Set the rotation degree you need with remote.
7. Set the time you would like it to pause with remote.
8. Press ON button with remote, and it will shoot pictures automatically.