


Parameter setting

Voice settings

Trun Off the power for the call pad,and Long press "CALL" button and then turn on power it display as "A - X",which indicates adjusting voice; loosen "CALL" button and then press the "+" or "-" button operate the voice adjustment (as shown below)



(1)




(2)



(3)

A—0: Play “dingdong” sound then speak the queue numbers in English

A—1: Play “dingdong” sound only



Call Number etting

Trun Off the power for the call pad,and Long press "CALL" button and then turn on power it display as "A - X",then press call button again,then the call pad screen display b---XXX then press the "+" or "-" button to make the maximum Call number (as shown below)

E.g: the maximum number is 100, the call number is 1 to 100;: the maximum number is 999,The Call number from 1 to 999 (as shown below)



After setting all the required parameters,press "CALL" button to save the settings line corresponds.