


## Multi Country Power Adapter--Handling & Use

Insert the required plug into the adapter. Plug is keyed to avoid incorrect insertion. Push the plug up to lock the plug on the adapter.

Remove the plug, please press the middle spring button and push down.

Make sure the plug is locked firmly in place before use.



### CAUTION :

Keep out of reach of children

NEVER insert the plug separately into a mains socket