BTX Installation Guide



-> Step1

Spread appropriate thermal conductive paste evenly on the CPU core.



--> Step3

Use the screw driver to lock tight the spring nut in order.



--> Step2

Make 4 holes on the CPU cooler base pass through the 4 cooper column of the backboard.



--> Step4

Connect the power cable of the fan to the motherboard. The assembly complete.