

### How to adjust the LED brightness









#### How to use sofeware for take video and Photo

Step1: Put CD to CD-ROM

Step2: Copy the file RsCap1.10 to the your PC disc



Step3: Contact our USB Wire cam to your PC and open RsCap1.10


Step4: Open the software and click"File", choose "Set capture file" to set video or photo save file.

Step5: Click"Capture",if you want record video, click"start capturt",click again to stop it.if you want take a photo,click the "shapshot" for take photo



### **Package**

- 1. The wire cam unit ×1
- 2. Color box ×1
- 3. users manual ×1
- 4. CD ×1



# Waterproof USB Wire CAM



### Feature:

1. Waterproof wire endoscope

- www.cablematic.com
- 2. High resolution with I/6 CMOS camera
- 3.6 LED low lux luminance lights can work better when the light is dark
- 4. XP system can watch video directly without install software, Vista or win 7 need use our software which in the CD
- 5.Can take photo and save it on your PC
- 6.Can record video, and save the video on your PC



## Specifications:

Function items	Spec Description
Camera	1/6"VGA COMS
Pixel	VGA 300K
Resolution	640×480, 352×288, 320×240, 176×144, 160×120
Capture Resolution	Up to 640×480
LED	6White LED bright light
Brightness	Auto
Exposed control	Auto
F/NO	2.8
Camera housing diameter	⊄7mm
Wide visual view angle	66°
LED switch	Adjustable lightness switch
Focal Distance	3CM-infinate
I/O Interface	USB 2.0/1.1
Color	24 bits color
Temperture	Up to 80℃