



USER'S MANUAL(4 seats series)


Step1




Step2



Step3



Step4



Seral number	Parts name	Quantity
1	M8*8 Screw	32
2	Support	8
3	Seat	4
4	Beam	1
5	M8*13 Screw	16
6	M10*100 Screw	4
7	Leg	2
8	Adjusts the foot	4
9	Armrest	2
10	M6 Hexagonal screw tap	1
11	M8 Hexagonal screw tap	1
12	Cannula	1