

BUY ON

www.cablematic.com

**Features**

Voltage: AC100-240V 50/60Hz

Power: 40W

**Light source:120pcs 5mm LEDs(36R,40G,40B,4A)**

4operation modes: Automatic running, DMX, Sound Active, Master/Slave

Sound controlled via built-in microphone

8ch or 16ch DMX channels

Packag size: 99\*32\*18 cm

Weight:10kg

**1,Digital display**

1,MENU(display ADDR): A001-A512

2,CHND(choose channel):8CH/16CH

3,SLND(master/slave): NAST is master, SL1/SL2

4,SOUN(sound control),press ENTER to confirm

5, LED: on(display will always on), off(display will go off in 20 seconds)

6,DISP(display)

7,TEST(testing mode)

8,HOUR(using time of light)

**2,DMX operation****8CH mode:**

CH1	0-255	Open light
CH2	0-255	All strobe
CH3	0-255	Select gobo
CH4	0-255	Select rotate gobo
CH5	0-255	Gobo rotate
CH6	0-255	Speed of gobo rotate
CH7	0-255	scan
CH8	0-255	Speed of scan

**16CH Mode:**

CH1	0-255	Open light
-----	-------	------------

CH2	0-255	All strobe
CH3	0-255	Select gobo
CH4	0-255	Select rotate gobo
CH5	0-255	Gobo rotate
CH6	0-255	Speed of gobo rotate
CH7	0-255	The first head scan
CH8	0-255	The second head scan
CH9	0-255	The third head scan
CH10	0-255	The fourth head scan
CH11	0-255	The fifth head scan
CH12	0-255	The sixth head scan
CH13	0-255	The seventh head scan
CH14	0-255	The eighth head scan
CH15	0-255	Speed of scan
CH16	0-127 128-255	Sound off Sound on

**Safety instruction****CAUTION!**

Be careful with your operations. With a dangerous voltage you can suffer a dangerous electric shock when touching the wires!  
Electric shock when touching the wires!

This device has left our premises in absolutely perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this manual.

**Please note:** Every information is subject to change without prior notice