

WHITE BLUFF BUILDING SUPPLY 4978 HWY 70 E
WHITE BLUFF, TN 37187
615-797-3111

Search Rental Catalog Search

Home > Additional Pages > Rental Equip Instructions > Sno-Kone Machine Instructions

## **Sno-Kone Machine Instructions**

- 1. Setup machine on a secure table top.
- 2. Plug in power cord.
- 3. Fill the hopper to within an inch of the top with ice cubes.
- 4. Switch the motor on. Wait for the motor to come to full speed (a minute or so).
- Push the pusher handle down against the ice in the hopper. Apply firm and even pressure to make the best snow.
- 6. Once ice has been shaved and has collected in the bottom compartment use a scoop to fill cones.
- 7. Apply any flavored syrups as desired.

CAUTION: Never put any object into the sno-kone machine body while the motor is running. Serious damage can occur to any body parts or objects that are placed inside the sno-kone machine hopper.

\*\* You will get your \$25 security deposit back as long as the sno-kone machine is returned clean with all of the supplies it was sent with. This includes both doors, scoop, drain tube and kone holder. \*\*

