

Fluke RLD2 Leak Detector Flashlight

Technical Data



RLD2 in leak detection mode

Features

Compact UV flashlight uncovers refrigerant leaks instantly.* The RLD2 combines leak detection ability with a bright flashlight to illuminate dark areas along with a laser pointer to pinpoint a leak.

- Instantly highlights leak detection dyes
- White LED light with 100,000 hour life
- Leak detection made easy
 - Vivid UV refrigerant leak detector finds the fault fast
 - Laser pointer pinpoints leak location
 - Bright flashlight with three LEDs penetrates dark areas
 - Key chain carabiner for convenience

*For use with standard leak detection dyes available in the market.



RLD2 with standard carabiner

Specifications

- Six UV/Blue LEDs highlight leak detection dyes
 - For use with standard leak detection dyes available in the market
- Laser pointer locates center of UV/Blue field
- Three white LED flashlight with 100,000 hour LED life
- Operating temperature: 0 °C to 50 °C (32 °F to 122 °F)
- Includes detachable key chain carabiner and AAA batteries
- One-year warranty

Functions

First Mode Flashlight First press activates unit and it is in the LAST mode selected TRIGGER press turns ON flashlight*	Second Mode UV light and Laser light Second press changes unit to the COMBO mode TRIGGER press turns ON UV light and laser light	
Third Mode UV light Third press changes unit to the NEXT mode TRIGGER press turns ON UV light	Fourth Mode Laser light Fourth press changes unit to the NEXT mode TRIGGER press turns ON laser light NEXT Press changes unit BACK to original flashlight	

* By holding in **TRIGGER** and then pressing **MODE** button the unit **LOCKS** into **FLASHLIGHT** mode- next **TRIGGER** press will release **LOCKED** state. This only occurs for the **FLASHLIGHT** mode.

Battery access.

Ordering information

RLD2 Leak Detector Flashlight

Included accessories

Key chain carabiner and batteries.

Standard leak detection dyes are not sold by Fluke.

Fluke. Keeping your world up and running.®

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

Fluke Europe B.V.

PO Box 1186, 5602 BD Eindhoven, The Netherlands

For more information call:

In the U.S.A. (800) 443-5853 or Fax (425) 446-5116
 In Europe/M-East/Africa +31 (0) 40 2675 200 or Fax +31 (0) 40 2675 222
 In Canada (800)-36-FLUKE or Fax (905) 890-6866
 From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116
 Web access: <http://www.fluke.com>

©2009 Fluke Corporation. Specifications subject to change without notice. Printed in U.S.A.
 4/2009 3471674 D-EN-N Rev A

Modification of this document is not permitted without written permission from Fluke Corporation.

