

カテゴリ	対応ブランド	型番	対応機種	JANコード	価格
ターンテーブル	各社対応	DS-PC-SL1200	Technics SL-1200 Pioneer PLX-1000 / 500	4534217720001	¥7,000
	Denon DJ	DS-PC-VL12	VL12 Prime	4534217721299	¥8,000
	Reeloc	DS-PC-RPTURNTABLE	RP7000 / 8000	4534217720018	¥7,000
	Stanton	DS-PC-VL12ST150	Stanton ST.150 / STR8.150	4534217720933	¥7,000
CDJ	Pioneer	DS-PC-CDJ850	CDJ-850	4534217720025	¥7,000
	Pioneer	DS-PC-CDJ900	CDJ-900	4534217720032	¥7,000
	Pioneer	DS-PC-CDJ900NXS	CDJ-900 NEXUS	4534217720049	¥7,000
	Pioneer	DS-PC-CDJ1000	CDJ-1000	4534217720056	¥7,000
	Pioneer	DS-PC-CDJ2000	CDJ-2000	4534217720063	¥8,000
	Pioneer	DS-PCFP-CDJ2000NEXUS	CDJ-2000 NEXUS	4534217720070	¥8,000
	Pioneer	DS-PCFP-CDJ2000NXS2	CDJ-2000NXS2	4534217720087	¥8,000
	Pioneer	DS-PC-XDJ700	XDJ-700	4534217720094	¥6,000
	Pioneer	DS-PC-XDJ1000	XDJ-1000	4534217720100	¥7,000
DJミキサー	各社対応	DS-PC-DJM800	Pioneer DJM-800,850,750,600,500 Allen&Heath Xone 43,62,92,DB2,DB4 Denon DNX1100,1600,1700	4534217720117	¥7,000
	Allen & Heath	DS-PC-XONE96	XONE 96	4534217721428	¥8,000
	Denon DJ	DS-PC-X1800	X1800 Prime	4534217720926	¥8,000
	Mixars	DS-PC-DUO	DUO	4534217720940	¥6,000
	NI	DS-PC-KONTROLZ2	Kontrol Z2	4534217720124	¥7,000
	Pioneer	DS-PC-DJM450	DJM-250 MK2 / DJM-450	4534217720780	¥6,000
	Pioneer	DS-PC-DJM750MK2	DJM-750 MK2	4534217721077	¥8,000
	Pioneer	DS-PC-DJM900	DJM-900 / 900nexus / 900SRT	4534217720131	¥8,000
	Pioneer	DS-PC-DJM900NXS2	DJM-900NXS2	4534217720148	¥8,000
	Pioneer	DS-PC-DJM2000	DJM-2000 / 2000nexus	4534217720155	¥8,000
	Pioneer	DS-PC-DJMS9	DJM-S9	4534217720162	¥8,000
	Pioneer	DS-PC-DJMS3	DJM-S3	4534217721084	¥8,000
	Rane	DS-PC-MP2015	MP2015	4534217720964	¥12,000
	Rane	DS-PC-RANE64	Sixty-Four	4534217720179	¥8,000
	Rane	DS-PC-RANE72	Seventy-Two	4534217721275	¥7,800
	Rane	DS-PC-TTM57II	TTM-57II	4534217720186	¥8,000
Reeloc	DS-PC-RMX908060	RMX-60 / 80 / 90 DVS	4534217720797	¥8,000	
DJコントローラ	Akai	DSLE-PC-AFXAMX	AFX / AMX	4534217720193	¥4,000
	Allen & Heath	DSLE-PCXONEK2	Xone K2	4534217720711	¥4,000
	Denon DJ	DS-PC-MC4000	MC4000	4534217721091	¥8,000
	Denon DJ	DS-PC-MC6000MK2	MC6000 / MC6000MK2	4534217721282	¥7,000
	Denon DJ	DS-PC-MCX8000	MCX8000	4534217720209	¥10,000
	Denon DJ	DS-PC-SC5000	SC5000 Prime	4534217720919	¥7,000
	NI	DS-PC-KONTROLFXZ1	Kontrol F1 / Z1 / X1Mk1&2	4534217720216	¥4,000
	NI	DS-PC-KONTROLS2	Kontrol S2	4534217720223	¥7,000
	NI	DS-PC-KONTROLS4	Kontrol S4 Mk1 / Mk2	4534217720230	¥8,000
	NI	DSLE-PC-KONTROLS2MK3	KONTROL S2 MK3	4534217721404	¥5,500
	NI	DS-PC-KONTROLS4MK3	KONTROL S4 MK3	4534217721398	¥8,000
	Novation	DS-PC-TWITCH	Twitch	4534217721367	¥7,000
	Numark	DS-PC-NUMARKNV	NV / NV II	4534217721466	¥7,000
	Pioneer	DS-PC-DDJRR	DDJ-RR	4534217720247	販売完了
	Pioneer	DS-PC-DDJSR2DDJRR	DDJ-RR / DDJ-SR2	4534217721114	¥8,000
	Pioneer	DS-PC-DDJ-RZX	DDJ-RZX	4534217720766	¥19,000

カテゴリ	対応ブランド	型番	対応機種	JANコード	価格
	Pioneer	DSLE-PC-DDJSB	DDJ-SB / SB2 / DDJ-RB	4534217720285	販売完了
	Pioneer	DSLE-PC-DDJSB3	DDJ-SB / SB2 / SB3 / DDJ-RB	4534217720285	¥5,500
	Pioneer	DSLE-PC-DDJ400	DDJ-400	4534217721381	¥5,500
	Pioneer	DS-PC-DDJ1000	DDJ-1000	4534217721251	¥7,200
	Pioneer	DS-PC-DDJSR	DDJ-SR	4534217720254	販売完了
	Pioneer	DS-PC-DDJSX3	DDJ-SX / SX2 / SX3 / DDJ-RX	4534217721312	¥8,000
	Pioneer	DS-PC-DDJSRX	DDJ-SX / SX2 / DDJ-RX	4534217720261	販売完了
	Pioneer	DS-PC-DDJSZRZ	DDJ-SZ / DDJ-RZ	4534217720278	¥10,000
	Pioneer	DSLE-PC-DDJWEG02	DDJ-WEG02Mk1 / Mk2	4534217720292	¥5,500
	Pioneer	DSLE-PC-DDJWEG03	DDJ-WEG03 / WEGO4	4534217720308	¥5,500
	Pioneer	DS-PC-DDJXP1	DDJ-XP1	4534217721244	¥5,500
	Pioneer	DS-PC-SP1	SP1	4534217720315	¥5,000
	Pioneer	DS-PC-XDJR1	XDJ-R1	4534217720322	¥8,000
	Pioneer	DS-PC-XDJRR	XDJ-RR	4534217721374	¥8,000
	Pioneer	DS-PC-XDJRX	XDJ-RX	4534217720339	¥8,000
	Pioneer	DS-PC-XDJRX2	XDJ-RX2	4534217721060	¥8,000
	Rane	DS-PC-RANE12	Twelve	4534217721268	¥7,800
	Reeloc	DS-PC-MIXON4	Mixon 4	4534217720629	¥8,000
	Reeloc	DSLE-PC-MIXTOUR	Mixtour	4534217720346	¥4,000
	Roland	DS-PC-DJ808	DJ-808	4534217720773	¥8,000
	Vestax	DS-PC-SPIN	Spin / Typhoon	4534217720353	¥6,000
	Vestax	DS-PC-VCI380	VCI-380	4534217720360	¥7,000
	Vestax	DS-PC-VCI400	VCI-400	4534217720377	¥8,000
DJ用エフェクター	Pioneer	DS-PC-RMX1000	RMX-1000	4534217720384	¥5,000
リズムマシン/グループボックス	Arturia	DS-PC-DRUMBRUTE	Drumbrute	4534217720742	¥8,000
	Dave Smith	DS-PC-TEMPEST	Tempest	4534217721206	¥8,000
	Korg	DS-PC-ELECTRIBE2	Electrabe 2 / Electrabe Sampler	4534217720414	¥5,500
	Korg	DSS-PC-VOLCA	Volca シリーズ (Keys, Bass, Beats, Sample)	4534217720421	¥4,000
	Novation	DS-PC-NCIRCUIT	Circuit	4534217720902	¥5,500
	Roland	DS-PC-BOUTIQUE	Boutiqueシリーズ (D-05 / TR-08 / SH-01 / SE-02 / JP-08 / JU-06 / JX-03 / TR-09 / TB-03 / VP-03 / A-01)	4534217721343	¥5,500
	Roland	DS-PC-TB303	TB-303	4534217721121	¥6,000
	Roland	DSS-PC-TR8	TR-8	4534217720438	¥6,000
	Roland	DS-PC-TR8S	TR-8S	4534217721336	¥6,000
	Roland	DS-PC-TR09TB03	TR-09 / TB-03 / JU-06 / JP-08 / JX-03	4534217720759	販売完了
	Roland	DS-PC-TR707	TR-707 / TR-727	4534217721138	¥8,000
	Roland	DS-PC-TR808	TR-808	4534217720445	¥8,000
	Roland	DS-PC-TR909	TR-909	4534217720452	¥8,000
シンセサイザー	Arturia	DSLE-PC-MICROBRUTE	Micro Brute	4534217720469	¥5,500
	Arturia	DSLE-PC-MINIBRUTE	Mini Brute	4534217720476	¥6,000
	Dave Smith	DS-PC-OB6	OB-6	4534217721190	¥13,500
	Dave Smith	DS-PC-PROPHET6	Prophet-6	4534217721183	¥13,500
	Elektron	DS-PC-ANALOGKEYS	Analog Keys	4534217720667	¥8,000
	Korg	DS-PC-MINILOGUE	Minilogue	4534217720483	¥8,000
	Korg	DS-PC-MONOLOGUE	Monologue	4534217720957	¥6,000
	Korg	DSS-PC-MS20M	MS-20 mini	4534217720490	¥8,000
	Moog	DS-PC-SUB37LITTLEPHATT	Little Phatty Stage 2 / Little Phatty SUB-37 / Subsequent 37	4534217720650	¥8,000

カテゴリ	対応ブランド	型番	対応機種	JANコード	価格
	Novation	DS-PC-CIRCUITMONO	Circuit Mono Station	4534217721145	¥6,000
	Novation	DS-PC-PEAK	Peak	4534217721152	¥8,000
	Pioneer	DS-PC-AS1	Toraiz AS-1	4534217721237	¥5,500
	Roland	DS-PC-JUNODS61	JUNO-DS61	4534217720803	¥18,000
	Roland	DSS-PC-SYSTEM1	Aira System 1	4534217720506	¥8,000
	Roland	DSS-PC-TB3	Aira TB-3	4534217720605	¥4,000
	Teenage Engineering	DS-PC-OP1	OP-1	4534217720674	¥5,500
	Teenage Engineering	DSLE-PC-OPZ	OP-Z	4534217721459	¥5,500
	Yamaha	DSLE-PC-YREFACE	Reface シリーズ (CS, DX, CP, YC)	4534217720513	¥5,500
サンプラー	Akai	DS-PC-MPCTOUCH	MPC Touch / MPC Live	4534217720643	¥7,000
	Akai	DS-PC-MPCX	MPC X	4534217721350	¥8,000
	Pioneer	DS-PC-DJS1000	DJS-1000	4534217721220	¥7,000
	Pioneer	DS-PC-SP16	Toraiz SP16	4534217720636	¥8,000
	Roland	DS-PC-SP404	SP-404 / 404A / 404SX	4534217721329	¥5,500
	Roland	DS-PC-SPDSX	SPD-SX	4534217721435	¥7,000
MIDIキーボード/コントローラ	Ableton	DS-PC-APUSH	Push	4534217720520	¥7,000
	Ableton	DS-PC-PUSH2	Push 2	4534217720537	¥7,000
	Akai	DS-PC-APC20	APC20	4534217720698	¥5,500
	Akai	DS-PC-APC40	APC40	4534217720704	¥7,000
	Akai	DS-PC-APC40MK2	APC40 MK2	4534217720544	¥7,000
	Arturia	DSLE-PC-BEATSTEP	Beatstep	4534217720391	¥4,000
	Arturia	DSLE-PC-BEATSTEPPRO	Beatstep Pro	4534217720407	¥4,000
	NI	DSS-PC-KONTROLS25	Kontrol S25	4534217720568	¥8,000
	NI	DSS-PC-KONTROLS49	Kontrol S49	4534217720575	¥13,500
	NI	DS-PC-KONTROLS49MK2	Kontrol S49 MK2	4534217721176	¥13,500
	NI	DS-PC-KONTROLS61	Kontrol S61	4534217720735	¥18,000
	NI	DS-PC-KONTROLS61MK2	Kontrol S61 MK2	4534217721169	¥18,000
	NI	DS-PC-MASCHINEJAM	Maschine JAM	4534217720728	¥7,000
	NI	DS-PC-MIKROMASCHINE	Maschine Mikro	4534217720889	¥5,000
	NI	DS-PC-MASCHINEMK2	Maschine MK2	4534217720582	¥7,000
	NI	DS-PC-MASCHINEMK3	Maschine MK3	4534217721107	¥7,000
	NI	DS-PC-MSTUDIO	Maschine Studio	4534217720896	¥8,000
オーディオインターフェイス	UA	DS-PC-APOLLLOTWIN	Apollo Twin	4534217720599	¥5,500
エフェクター/ミキサー	Roland	DS-PC-MX1	AIRA MX-1	4534217720681	¥6,000
	Roland	DSS-PC-VT3	AIRA VT-3	4534217720612	¥4,000