



## FAX ERROR & RESULT CODES

### FAX RESULT CODES

- 1000 = fax pending
- 4000 = fax failed
- 5000 = fax resource issue
- 5100 = fax request blocked
- 5200 = fax rendering issue
- 6000 = fax connect failed
- 6100 = fax number busy
- 6200 = fax machine not answering
- 6300 = fax detection failed
- 6400 = fax pickup failed
- 6500 = fax detection failed
- 6600 = fax detection timeout
- 6800 = fax negotiation failed
- 7000 = fax training failed
- 8000 = fax transmit failed
- 9000 = fax failed

### FAX ERROR CODES

Use the last 4 digits of the error code to match the appropriate code shown below to determine error cause.

Line "infoEx" defines error.

```
#####  
## 0000  
#####
```

```
[fax-0]  
type=Normal  
context=Info  
code=0  
apiRef=BT_STATUS_OK  
info=OK  
infoEx=
```

#####

## 2000

#####

[fax-2000]

type=Error

context=API

code=2000

apiRef=API\_ERR\_UNCLASSIFIED

info=Fax attempt failed

infoEx=No further info provided

[fax-2001]

type=Error

context=API

code=2001

apiRef=API\_ERR\_FILEIO

info=Fax attempt failed

infoEx=File I/O error occurred

[fax-2002]

type=Error

context=API

code=2002

apiRef=API\_ERR\_FILEFORMAT

info=Fax attempt failed

infoEx=Bad file format

[fax-2003]

type=Error

context=API

code=2003

apiRef=API\_ERR\_BOARDCAPABILITY

info=Fax attempt failed

infoEx=Board firmware does not support capability

[fax-2004]

type=Error

context=API

code=2004

apiRef=API\_ERR\_NOTCONNECTED

info=Fax attempt failed  
infoEx=Channel not in proper state

[fax-2005]  
type=Error  
context=API  
code=2005  
apiRef=API\_ERR\_BADPARAMETER  
info=Fax attempt failed  
infoEx=Bad parameter value used

[fax-2006]  
type=Error  
context=API  
code=2006  
apiRef=API\_ERR\_MEMORY  
info=Fax attempt failed  
infoEx=Memory allocation error

[fax-2007]  
type=Error  
context=API  
code=2007  
apiRef=API\_ERR\_BADSTATE  
info=Fax attempt failed  
infoEx=The channel not in a required state

[fax-2008]  
type=Error  
context=API  
code=2008  
apiRef=API\_ERR\_TOO\_SOON  
info=Fax attempt failed  
infoEx=Dialing was attempted too soon

[fax-2009]  
type=Error  
context=API  
code=2009  
apiRef=API\_ERR\_BUSY  
info=Fax attempt failed  
infoEx=Resource busy

[fax-2010]  
type=Error  
context=API  
code=2010  
apiRef=API\_ERR\_DRV\_OPEN\_ERROR  
info=Fax attempt failed  
infoEx=Driver open call failed, invalid channel or driver not correctly installed

[fax-2011]  
type=Error  
context=API  
code=2011  
apiRef=API\_ERR\_DRV\_IOCTL\_ERR  
info=Fax attempt failed  
infoEx=Driver call failed

[fax-2012]  
type=Error  
context=API  
code=2012  
apiRef=API\_ERR\_VERSION  
info=Fax attempt failed  
infoEx=Incompatible driver version

[fax-2013]  
type=Error  
context=API  
code=2013  
apiRef=API\_ERR\_INVALID\_PORT  
info=Fax attempt failed  
infoEx=Invalid fax port

[fax-2014]  
type=Error  
context=API  
code=2014  
apiRef=API\_ERR\_RINGING  
info=Fax attempt failed  
infoEx=Ringling occurred during dialing attempt

[fax-2015]  
type=Error  
context=API

code=2015  
apiRef=API\_ERR\_INFOPKT\_NESTING  
info=Fax attempt failed  
infoEx=Indir infopkt nesting level too deep

[fax-2016]  
type=Error  
context=API  
code=2016  
apiRef=API\_ERR\_MAX\_TAGS  
info=Fax attempt failed  
infoEx=Maximum number of TIFF tags exceeded

[fax-2017]  
type=Error  
context=API  
code=2017  
apiRef=API\_ERR\_LOCK\_FAILED  
info=Fax attempt failed  
infoEx=An attempt to gain a lock failed

[fax-2018]  
type=Error  
context=API  
code=2018  
apiRef=API\_ERR\_INSUFF\_BUFFER  
info=Fax attempt failed  
infoEx=Buffer size too small to receive data

[fax-2019]  
type=Error  
context=API  
code=2019  
apiRef=API\_ERR\_INVALID\_DEST\_ADDR  
info=Fax attempt failed  
infoEx=Destination address not found or invalid

[fax-2020]  
type=Error  
context=API  
code=2020  
apiRef=API\_ERR\_PACKET\_CREATION  
info=Fax attempt failed

infoEx=Packet or command creation error

[fax-2021]

type=Error

context=API

code=2021

apiRef=API\_ERR\_PACKET\_PARSE

info=Fax attempt failed

infoEx=Packet or command parse error

[fax-2022]

type=Error

context=API

code=2022

apiRef=API\_ERR\_PACKET\_SEND

info=Fax attempt failed

infoEx=Packet send error

[fax-2023]

type=Error

context=API

code=2023

apiRef=API\_ERR\_PACKET\_RECEIVE

info=Fax attempt failed

infoEx=Packet receive error

[fax-2024]

type=Error

context=API

code=2024

apiRef=API\_ERR\_DATA

info=Fax attempt failed

infoEx=DATA encountered during command processing

[fax-2025]

type=Error

context=API

code=2025

apiRef=API\_ERR\_INVALID\_BOARD\_PARAM

info=Fax attempt failed

infoEx=Invalid parameter values received from board

[fax-2026]

type=Error  
context=API  
code=2026  
apiRef=API\_ERR\_FIRMWARE\_ERR\_DETECTED  
info=Fax attempt failed  
infoEx=Firmware detected an error

[fax-2027]  
type=Error  
context=API  
code=2027  
apiRef=API\_ERR\_MODULE\_REMOVED  
info=Fax attempt failed  
infoEx=Module was removed

[fax-2028]  
type=Error  
context=API  
code=2028  
apiRef=API\_ERR\_BOARD\_NO\_RESPONSE  
info=Fax attempt failed  
infoEx=Board not responding

[fax-2029]  
type=Error  
context=API  
code=2029  
apiRef=API\_ERR\_ASYNC\_LP\_ERR  
info=Fax attempt failed  
infoEx=Async-LP value error

[fax-2030]  
type=Error  
context=API  
code=2030  
apiRef=API\_ERR\_ASYNC\_CONTEXT\_ERR  
info=Fax attempt failed  
infoEx=Async context error

[fax-2031]  
type=Error  
context=API  
code=2031

apiRef=API\_ERR\_DRV\_RESOURCES  
info=Fax attempt failed  
infoEx=Driver out of resources

[fax-2032]  
type=Error  
context=API  
code=2032  
apiRef=API\_ERR\_MODULE\_RESET\_FAILURE  
info=Fax attempt failed  
infoEx=Module reset failure

[fax-2033]  
type=Error  
context=API  
code=2033  
apiRef=API\_ERR\_MODULE\_I2O\_FAILURE  
info=Fax attempt failed  
infoEx=Module I2O enable failure

[fax-2034]  
type=Error  
context=API  
code=2034  
apiRef=API\_ERR\_MODULE\_CONFIG\_TIMEOUT  
info=Fax attempt failed  
infoEx=No valid response for module configuration

[fax-2035]  
type=Error  
context=API  
code=2035  
apiRef=API\_ERR\_NO\_TRANSPORT  
info=Fax attempt failed  
infoEx=No transport layer

[fax-2036]  
type=Error  
context=API  
code=2036  
apiRef=API\_ERR\_NON\_SUPPORTED\_FEATURE  
info=Fax attempt failed  
infoEx=Unsupported feature



#####

## 3200

#####

[fax-3257]  
type=Dialing  
context=Info  
code=3257  
apiRef=DIAL\_OK  
info=Failed to detect fax machine  
infoEx=Dialing complete

[fax-3258]  
type=Dialing  
context=Info  
code=3258  
apiRef=DIAL\_NO\_DIAL\_TONE  
info=No dial tone on line  
infoEx=No dial tone detected

[fax-3259]  
type=Dialing  
context=Info  
code=3259  
apiRef=DIAL\_NO\_LOOP\_CUR  
info=Failed to dial fax number  
infoEx=No loop current detected

[fax-3260]  
type=Dialing  
context=Info  
code=3260  
apiRef=DIAL\_LOCAL\_IN\_USE  
info=Failed to dial fax number  
infoEx=Local phone in use

[fax-3261]  
type=Dialing  
context=Info  
code=3261  
apiRef=DIAL\_TRUNK\_BUSY

info=Telco resources busy  
infoEx=Busy trunk line detected

[fax-3265]  
type=Dialing  
context=Info  
code=3265  
apiRef=DIAL\_SLOT\_BUSY  
info=Failed to dial fax number  
infoEx=T1 time slot busy

[fax-3266]  
type=Dialing  
context=Info  
code=3266  
apiRef=DIAL\_CALL\_COLLISION  
info=Failed to dial fax number  
infoEx=Call collision detected

[fax-3267]  
type=Dialing  
context=Info  
code=3267  
apiRef=DIAL\_NO\_WINK  
info=Failed to dial fax number  
infoEx=No wink signal

[fax-3268]  
type=Dialing  
context=Info  
code=3268  
apiRef=DIAL\_ISDN\_INVALID  
info=Invalid ISDN dial string  
infoEx=

[fax-3269]  
type=Dialing  
context=Info  
code=3269  
apiRef=DIAL\_JP\_REDIAL\_FAIL  
info=Failed to dial fax number  
infoEx=Redial attempted too soon

#####

## 3300

#####

[fax-3301]  
type=Dialing  
context=Final Call Progress  
code=3301  
apiRef=FCP\_BUSY1  
info=Fax number busy  
infoEx=Remote end busy or off-hook

[fax-3302]  
type=Dialing  
context=Final Call Progress  
code=3302  
apiRef=FCP\_BUSY2  
info=Fax number busy  
infoEx=Remote end busy or off-hook

[fax-3303]  
type=Dialing  
context=Final Call Progress  
code=3303  
apiRef=FCP\_ROBUSY  
info=Fax number unavailable  
infoEx=No available lines on remote end to answer call

[fax-3304]  
type=Dialing  
context=Final Call Progress  
code=3304  
apiRef=FCP\_RECALL  
info=Fax detection interrupted  
infoEx=Recall dial tone detected

[fax-3306]  
type=Dialing  
context=Final Call Progress  
code=3306  
apiRef=FCP\_PULSE  
info=Fax attempt failed

infoEx=

[fax-3308]  
type=Dialing  
context=Final Call Progress  
code=3308  
apiRef=FCP\_RING1  
info=No answer  
infoEx=Remote end is ringing

[fax-3309]  
type=Dialing  
context=Final Call Progress  
code=3309  
apiRef=FCP\_RING2  
info=No answer  
infoEx=Remote end is ringing

[fax-3316]  
type=Dialing  
context=Final Call Progress  
code=3316  
apiRef=FCP\_HUMAN  
info=Failed to detect fax machine  
infoEx=Remote end answered but did not initiate fax sequence

[fax-3317]  
type=Dialing  
context=Final Call Progress  
code=3317  
apiRef=FCP\_ANSWER  
info=No fax machine detected  
infoEx=Remote end answered but did not initiate fax sequence

[fax-3318]  
type=Dialing  
context=Final Call Progress  
code=3318  
apiRef=FCP\_DIALTON\_ON  
info=Fax attempt failed  
infoEx=Possible dial tone issue

[fax-3324]

type=Dialing  
context=Final Call Progress  
code=3324  
apiRef=FCP\_SILENCE  
info=Fax machine not detected  
infoEx=No fax CNG tone detected after answering call

[fax-3325]  
type=Dialing  
context=Final Call Progress  
code=3325  
apiRef=FCP\_RINGNOANS  
info=No answer  
infoEx=Remote end was ringing but did not answer

[fax-3326]  
type=Dialing  
context=Final Call Progress  
code=3326  
apiRef=FCP\_G2DETCT  
info=Incompatible remote fax device  
infoEx=Group 2 fax machine detected. No support for G2 devices

[fax-3327]  
type=Dialing  
context=Final Call Progress  
code=3327  
apiRef=FCP\_SITINC  
info=Call interrupted  
infoEx=Remote end indicated failure. Telephone number or class of service restricted

[fax-3328]  
type=Dialing  
context=Final Call Progress  
code=3328  
apiRef=FCP\_QUIET  
info=Fax machine did not pick-up  
infoEx=No energy detected on the line before timeout expired

[fax-3329]  
type=Dialing  
context=Final Call Progress  
code=3329

apiRef=FCP\_SITVACODE  
info=Fax number unavailable  
infoEx=Vacant tone detected. Number may be invalid or out of service

[fax-3330]  
type=Dialing  
context=Final Call Progress  
code=3330  
apiRef=FCP\_SITREORD  
info=Fax number unavailable  
infoEx=Reorder tone detected. Number may be invalid or out of service

[fax-3331]  
type=Dialing  
context=Final Call Progress  
code=3331  
apiRef=FCP\_SITNOCIR  
info=Failed to initiate call  
infoEx=No circuit detected. Line might be dead

[fax-3332]  
type=Dialing  
context=Final Call Progress  
code=3332  
apiRef=FCP\_CNGDETCT  
info=Fax machine detected  
infoEx=CNG fax calling tone detected

[fax-3333]  
type=Dialing  
context=Final Call Progress  
code=3333  
apiRef=FCP\_RMTOFFHK  
info=Fax attempt failed  
infoEx=Remote off hook detected

[fax-3334]  
type=Dialing  
context=Final Call Progress  
code=3334  
apiRef=FCP\_SPECIALCP  
info=Fax attempt failed  
infoEx=Special CP tone detected

[fax-3339]  
type=Dialing  
context=Final Call Progress  
code=3339  
apiRef=FCP\_ANSWER\_TONE\_DETECT  
info=Fax machine detected  
infoEx=Fax machine CED tone detected and transmission started

[fax-3340]  
type=Dialing  
context=Final Call Progress  
code=3340  
apiRef=FCP\_UNKNOWN  
info=Fax attempt failed  
infoEx=Unknown CP result

[fax-3348]  
type=Dialing  
context=Final Call Progress  
code=3348  
apiRef=FCP\_ISDN\_CALL\_PROGRESS  
info=Call progress  
infoEx=ISDN call progress

[fax-3349]  
type=Dialing  
context=Final Call Progress  
code=3349  
apiRef=FCP\_ISDN\_CALL\_COLLISION  
info=Call collision occurred  
infoEx=Call collision occurred

[fax-3352]  
type=Dialing  
context=Final Call Progress  
code=3352  
apiRef=WAIT\_FOR\_CALL\_OK  
info=Fax machine detected  
infoEx=Fax machine detected and transmission started

[fax-3353]  
type=Dialing

context=Final Call Progress  
code=3353  
apiRef=WAIT\_FOR\_CALL\_TIMEOUT  
info=No call received  
infoEx=Timeout expired

#####  
## 3500  
#####

[fax-3500]  
type=Dialing  
context=Error  
code=3500  
apiRef=DIAL\_UNKNOWN  
info=Failed to dial fax number  
infoEx=Unknown dialing error

#####  
## 4000  
#####

[fax-4000]  
type=Hangup  
context=Call Placement  
code=4000  
apiRef=HNG\_NORMAL\_XMIT  
info=Transmission complete  
infoEx=Normal and proper end of connection

[fax-4001]  
type=Hangup  
context=Call Placement  
code=4001  
apiRef=HNG\_RNG\_DET  
info=Failed to connect with remote device  
infoEx=Ring detected without a successful handshake

[fax-4002]



type=Hangup  
context=Call Placement  
code=4002  
apiRef=HNG\_ABORT  
info=Call aborted  
infoEx=Call aborted

[fax-4003]  
type=Hangup  
context=Call Placement  
code=4003  
apiRef=HNG\_NO\_LOOP\_CURRENT  
info=Connection dropped  
infoEx=No loop current or A/B signaling bits

[fax-4004]  
type=Hangup  
context=Call Placement  
code=4004  
apiRef=HNG\_ISDN\_DISCONNECT  
info=Connection disconnected  
infoEx=ISDN disconnection

[fax-4011]  
type=Hangup  
context=Transmit Phase A  
code=4011  
apiRef=HNG\_T1\_TIMEOUT  
info=Transmission timed out  
infoEx=No answer, T.30 T1 time-out

[fax-4020]  
type=Hangup  
context=Transmit Phase B  
code=4020  
apiRef=HNG\_XMITB\_TIMEOUT  
info=Transmission failed  
infoEx=Unspecified transmit Phase B error

[fax-4021]  
type=Hangup  
context=Transmit Phase B  
code=4021

apiRef=HNG\_XMITB\_NORM  
info=Transmission failed  
infoEx=Remote cannot receive or send

[fax-4022]  
type=Hangup  
context=Transmit Phase B  
code=4022  
apiRef=HNG\_XMIT\_MISC  
info=Transmission failed  
infoEx=COMREC error, Phase B transmit

[fax-4023]  
type=Hangup  
context=Transmit Phase B  
code=4023  
apiRef=HNG\_XMITB\_COMREC\_VCNR  
info=Transmission failed  
infoEx=COMREC invalid command received

[fax-4024]  
type=Hangup  
context=Transmit Phase B  
code=4024  
apiRef=HNG\_XMITB\_SE  
info=Transmission failed  
infoEx=RSPREC error

[fax-4025]  
type=Hangup  
context=Transmit Phase B  
code=4025  
apiRef=HNG\_XMITB\_DCS\_FTC  
info=Transmission failed  
infoEx=DCS sent three times; DCS not recognized

[fax-4026]  
type=Hangup  
context=Transmit Phase B  
code=4026  
apiRef=HNG\_XMITB\_DIS\_FTC  
info=Transmission failed  
infoEx=DIS/DTC received three times; DCS not recognized

[fax-4027]  
type=Hangup  
context=Transmit Phase B  
code=4027  
apiRef=HNG\_XMITB\_TRAINFAIL  
info=Transmission failed  
infoEx=Failure to train

[fax-4028]  
type=Hangup  
context=Transmit Phase B  
code=4028  
apiRef=HNG\_XMITB\_RSPREC\_VCNR  
info=Transmission failed  
infoEx=RSPREC invalid response received

[fax-4029]  
type=Hangup  
context=Transmit Phase B  
code=4029  
apiRef=HNG\_XMITB\_COMREC\_DCN  
info=Transmission failed  
infoEx=DCN received in COMREC

[fax-4030]  
type=Hangup  
context=Transmit Phase B  
code=4030  
apiRef=HNG\_XMITB\_RSPREC\_DCN  
info=Transmission failed  
infoEx=DCN received in RSPREC

[fax-4033]  
type=Hangup  
context=Transmit Phase B  
code=4033  
apiRef=HNG\_PHASEB\_INCOMPAT\_FMT  
info=Transmission failed  
infoEx=Incompatible fax formats, for example, a page width mismatch

[fax-4034]  
type=Hangup

context=Transmit Phase B  
code=4034  
apiRef=HNG\_XMITB\_INVALID\_DMACNT  
info=Transmission failed  
infoEx=Invalid DMA count specified for transmitter

[fax-4035]  
type=Hangup  
context=Transmit Phase B  
code=4035  
apiRef=HNG\_XMITB\_FTM\_NOECM  
info=Transmission failed  
infoEx=Binary File Transfer specified, but ECM not enabled on transmitter

[fax-4036]  
type=Hangup  
context=Transmit Phase B  
code=4036  
apiRef=HNG\_XMITB\_INCOMP\_FTM  
info=Transmission failed  
infoEx=Binary File Transfer mode specified, but not supported by receiver

[fax-4037]  
type=Hangup  
context=Transmit Phase B  
code=4037  
apiRef=HNG\_XMITB\_INCOMP\_EFF  
info=Transmission failed  
infoEx=Remote does not support EFF page options required by host

[fax-4038]  
type=Hangup  
context=Transmit Phase B  
code=4038  
apiRef=HNG\_XMITB\_NOEFF  
info=Transmission failed  
infoEx=Remote does not support EFF page coding

[fax-4040]  
type=Hangup  
context=Transmit Phase D  
code=4040  
apiRef=HNG\_XMITD\_RR\_NORES

info=Transmission failed  
infoEx=No response to RR after three tries

[fax-4041]  
type=Hangup  
context=Transmit Phase D  
code=4041  
apiRef=HNG\_XMITD\_CTC\_NORES  
info=Transmission failed  
infoEx=No response to CTC, or response was not CTR

[fax-4042]  
type=Hangup  
context=Transmit Phase D  
code=4042  
apiRef=HNG\_XMITD\_T5TO\_RR  
info=Transmission failed  
infoEx=T5 time-out since receiving first RNR

[fax-4043]  
type=Hangup  
context=Transmit Phase D  
code=4043  
apiRef=HNG\_XMITD\_NOCONT\_NSTMSG  
info=Transmission failed  
infoEx=Do not continue with next message after receiving ERR

[fax-4044]  
type=Hangup  
context=Transmit Phase D  
code=4044  
apiRef=HNG\_XMITD\_ERRRES\_EOREOP  
info=Transmission failed  
infoEx=ERR response to EOR-EOP or EOR-PRI-EOP

[fax-4045]  
type=Hangup  
context=Transmit Phase D  
code=4045  
apiRef=HNG\_XMITD\_RTN\_DCN  
info=Transmission failed  
infoEx=Transmitted DCN after receiving RTN

[fax-4046]  
type=Hangup  
context=Transmit Phase D  
code=4046  
apiRef=HNG\_XMITD\_PPR\_EOR  
info=Transmission failed  
infoEx=EOR-MPS, EOR-EOM, EOR-NULL, EOR-PRI-MPS, or EOR-PRI-EOM sent after fourth PPR received

[fax-4051]  
type=Hangup  
context=Transmit Phase D  
code=4051  
apiRef=HNG\_XMITD\_SE  
info=Transmission failed  
infoEx=RSPREC error

[fax-4052]  
type=Hangup  
context=Transmit Phase D  
code=4052  
apiRef=HNG\_XMITD\_MPS\_FTC  
info=Transmission failed  
infoEx=No response to MPS, repeated three times

[fax-4053]  
type=Hangup  
context=Transmit Phase D  
code=4053  
apiRef=HNG\_XMITD\_MPS\_VCNR  
info=Transmission failed  
infoEx=Invalid response to MPS

[fax-4054]  
type=Hangup  
context=Transmit Phase D  
code=4054  
apiRef=HNG\_XMITD\_EOP\_FTC  
info=Transmission failed  
infoEx=No response to EOP repeated three times

[fax-4055]  
type=Hangup

context=Transmit Phase D  
code=4055  
apiRef=HNG\_XMITD\_EOP\_VCNR  
info=Transmission failed  
infoEx=Invalid response to EOP

[fax-4056]  
type=Hangup  
context=Transmit Phase D  
code=4056  
apiRef=HNG\_XMITD\_EOM\_FTC  
info=Transmission failed  
infoEx=No response to EOM, repeated three times

[fax-4057]  
type=Hangup  
context=Transmit Phase D  
code=4057  
apiRef=HNG\_XMITD\_EOM\_VCNR  
info=Transmission failed  
infoEx=Invalid response to EOM

[fax-4060]  
type=Hangup  
context=Transmit Phase D  
code=4060  
apiRef=HNG\_XMITD\_RSPREC\_DCN  
info=Transmission failed  
infoEx=DCN received in RSPREC

[fax-4061]  
type=Hangup  
context=Transmit Phase D  
code=4061  
apiRef=HNG\_XMITD\_PPSNULL\_NORES  
info=Transmission failed  
infoEx=No response received after third try for PPS-NULL

[fax-4062]  
type=Hangup  
context=Transmit Phase D  
code=4062  
apiRef=HNG\_XMITD\_PPSMPS\_NORES

info=Transmission failed  
infoEx=No response received after third try for PPS-MPS

[fax-4063]  
type=Hangup  
context=Transmit Phase D  
code=4063  
apiRef=HNG\_XMITD\_PPSEOP\_NORES  
info=Transmission failed  
infoEx=No response received after third try for PPS-EOP

[fax-4064]  
type=Hangup  
context=Transmit Phase D  
code=4064  
apiRef=HNG\_XMITD\_PPSEOM\_NORES  
info=Transmission failed  
infoEx=No response received after third try for PPS-EOM

[fax-4065]  
type=Hangup  
context=Transmit Phase D  
code=4065  
apiRef=HNG\_XMITD\_EORNULL\_NORES  
info=Transmission failed  
infoEx=No response received after third try for EOR-NULL

[fax-4066]  
type=Hangup  
context=Transmit Phase D  
code=4066  
apiRef=HNG\_XMITD\_EORMPS\_NORES  
info=Transmission failed  
infoEx=No response received after third try for EOR-MPS

[fax-4067]  
type=Hangup  
context=Transmit Phase D  
code=4067  
apiRef=HNG\_XMITD\_EOREOP\_NORES  
info=Transmission failed  
infoEx=No response received after third try for EOR-EOP



[fax-4068]  
type=Hangup  
context=Transmit Phase D  
code=4068  
apiRef=HNG\_XMITD\_EOREOM\_NORES  
info=Transmission failed  
infoEx=No response received after third try for EOR-EOM

[fax-4070]  
type=Hangup  
context=Receive Phase B  
code=4070  
apiRef=HNG\_RCVB\_TIMEOUT  
info=Transmission failed  
infoEx=Unspecified receive Phase B error

[fax-4071]  
type=Hangup  
context=Receive Phase B  
code=4071  
apiRef=HNG\_RCVB\_SE  
info=Transmission failed  
infoEx=RSPREC error

[fax-4072]  
type=Hangup  
context=Receive Phase B  
code=4072  
apiRef=HNG\_RCVB\_MISC  
info=Transmission failed  
infoEx=COMREC error

[fax-4073]  
type=Hangup  
context=Receive Phase B  
code=4073  
apiRef=HNG\_T2\_PNOTREC  
info=Transmission failed  
infoEx=T.30 T2 time-out, expected page not received

[fax-4074]  
type=Hangup  
context=Receive Phase B

code=4074  
apiRef=HNG\_RCVB\_T1\_TIMEOUT  
info=Transmission failed  
infoEx=T.30 T1 time-out after EOM received

[fax-4075]  
type=Hangup  
context=Receive Phase B  
code=4075  
apiRef=HNG\_NORMAL\_RCV  
info=Transmission failed  
infoEx=DCN received in COMREC

[fax-4076]  
type=Hangup  
context=Receive Phase B  
code=4076  
apiRef=HNG\_RCVB\_RSPREC\_DCN  
info=Transmission failed  
infoEx=DCN received in RSPREC

[fax-4077]  
type=Hangup  
context=Receive Phase B  
code=4077  
apiRef=HNG\_T2\_TIMEOUT  
info=Transmission failed  
infoEx=T.30 T2 time-out, expected page received

[fax-4078]  
type=Hangup  
context=Receive Phase B  
code=4078  
apiRef=HNG\_RCVB\_INVALID\_DMA\_CNT  
info=Transmission failed  
infoEx=Invalid DMA count specified for receiver

[fax-4079]  
type=Hangup  
context=Receive Phase B  
code=4079  
apiRef=HNG\_RCVB\_FTM\_NOECM  
info=Transmission failed

infoEx=Binary File Transfer specified, but ECM not supported by receiver

[fax-4080]  
type=Hangup  
context=Receive Phase B  
code=4080  
apiRef=HNG\_RCVB\_INCOMPAT\_REM  
info=Transmission failed  
infoEx=Remote machine is incompatible

[fax-4101]  
type=Hangup  
context=Receive Phase D  
code=4101  
apiRef=HNG\_RCVD\_SE\_VCNR  
info=Transmission failed  
infoEx=RSPREC invalid response received

[fax-4102]  
type=Hangup  
context=Receive Phase D  
code=4102  
apiRef=HNG\_RCVD\_COMREC\_VCNR  
info=Transmission failed  
infoEx=COMREC invalid response received

[fax-4103]  
type=Hangup  
context=Receive Phase D  
code=4103  
apiRef=HNG\_RCVD\_T3TO\_NORES  
info=Transmission failed  
infoEx=T3 time-out; no local response for remote voice interrupt

[fax-4104]  
type=Hangup  
context=Receive Phase D  
code=4104  
apiRef=HNG\_RCVD\_T2TO  
info=Transmission failed  
infoEx=T2 time-out; no command received after responding RNR

[fax-4105]

type=Hangup  
context=Receive Phase D  
code=4105  
apiRef=HNG\_RCVD\_DCN\_COMREC  
info=Transmission failed  
infoEx=DCN received for command received

[fax-4106]  
type=Hangup  
context=Receive Phase D  
code=4106  
apiRef=HNG\_RCVD\_COMREC\_ERR  
info=Transmission failed  
infoEx=Command receive error

[fax-4107]  
type=Hangup  
context=Receive Phase D  
code=4107  
apiRef=HNG\_RCVD\_BLKCT\_ERR  
info=Transmission failed  
infoEx=Receive block count error in ECM mode

[fax-4108]  
type=Hangup  
context=Receive Phase D  
code=4108  
apiRef=HNG\_RCVD\_PGCT\_ERR  
info=Transmission failed  
infoEx=Receive page count error in ECM mode

[fax-4109]  
type=Hangup  
context=Receive Phase D  
code=4109  
apiRef=HNG\_RCVD\_EOR  
info=Transmission failed  
infoEx=EOR received in phase D

[fax-4110]  
type=Hangup  
context=Receive Phase D  
code=4110

apiRef=HNG\_RCVD\_RNRTO  
info=Transmission failed  
infoEx=Timeout while repeating RNR

[fax-4150]  
type=Hangup  
context=Receive Phase C  
code=4150  
apiRef=HNG\_RCVC\_EOL\_TIMEOUT  
info=Transmission failed  
infoEx=No EOL received in a 5-second period

[fax-4151]  
type=Hangup  
context=Receive Phase C  
code=4151  
apiRef=HNG\_RCVC\_BAD\_MMR  
info=Transmission failed  
infoEx=Bad MMR data received from remote

[fax-4240]  
type=Hangup  
context=Miscellaneous  
code=4240  
apiRef=HNG\_INTERRUPT\_ACK  
info=Transmission failed  
infoEx=No interrupt acknowledge, time-out

[fax-4241]  
type=Hangup  
context=Miscellaneous  
code=4241  
apiRef=HNG\_COMM\_FAULT  
info=Transmission failed  
infoEx=Loop current still present while playing reorder tone after time-out

[fax-4242]  
type=Hangup  
context=Miscellaneous  
code=4242  
apiRef=HNG\_T30\_HOLDUP  
info=Transmission failed  
infoEx=T.30 holdup time-out

[fax-4243]  
type=Hangup  
context=Miscellaneous  
code=4243  
apiRef=HNG\_HOLDUP\_DCN  
info=Transmission failed  
infoEx=DCN received from host in receive holdup section for FAX PAD mode

[fax-4244]  
type=Hangup  
context=Miscellaneous  
code=4244  
apiRef=HNG\_HOLDUP\_DCN\_NON\_FPAD  
info=Transmission failed  
infoEx=DCN received from host in receive holdup section for non-FAX PAD mode

[fax-4500]  
type=Hangup  
context=API  
code=4500  
apiRef=HNG\_ERROR\_INTERRUPT  
info=Transmission failed  
infoEx=An error interrupt occurred, indicating a problem with the board too severe to continue

[fax-4501]  
type=Hangup  
context=API  
code=4501  
apiRef=HNG\_INTERRUPT\_OVERRUN  
info=Transmission failed  
infoEx=The application was unable to process interrupts from the board fast enough, and information was lost

[fax-4502]  
type=Hangup  
context=API  
code=4502  
apiRef=HNG\_UNEXPECTED\_IRSDONE  
info=Transmission failed  
infoEx=The channel generated an unexpected 03 (reset done) or 7F interrupt, indicating the existence of a firmware or hardware problem

[fax-4503]  
type=Hangup  
context=API  
code=4503  
apiRef=HNG\_IOCTL\_ERROR  
info=Transmission failed  
infoEx=An API command to the driver returned an error value, indicating that the driver or the operating system detected an error

[fax-4504]  
type=Hangup  
context=API  
code=4504  
apiRef=HNG\_OVERLAY\_DLOAD\_ERR  
info=Transmission failed  
infoEx=Error reported ad termination of fax overlay download

[fax-4505]  
type=Hangup  
context=API  
code=4505  
apiRef=HNG\_MAX\_TIMEOUT  
info=Transmission failed  
infoEx=Maximum timeout exceeded

#####  
## 5000  
#####

[fax-5000]  
type=User  
context=Terminated  
code=5000  
apiRef=BT\_STATUS\_USER\_TERMINATED  
info=Transmission interrupted  
infoEx=User function caused interruption

#####  
## 6000  
#####

[fax-6000]  
type=Timeout  
context=Time  
code=6000  
apiRef=API\_TO\_TIME  
info=Transmission timeout  
infoEx=Timeout due to total time elapsed

[fax-6001]  
type=Timeout  
context=Silence  
code=6001  
apiRef=API\_TO\_SILENCE  
info=Transmission timeout  
infoEx=Timeout due to silence timeout

#####  
## 7000  
#####

[fax-7000]  
type=Alert  
context=  
code=7000  
apiRef=BT\_STATUS\_ALERT  
info=Transmission interrupted  
infoEx=System alert occurred

#####  
## 8000  
#####

[fax-8000]  
type=Error  
context=API  
code=8000  
apiRef=  
info=Unknown error  
infoEx=Fax transmit failed



```
#####  
## 9000  
#####
```

```
[fax-9000]  
type=Error  
context=API  
code=9000  
apiRef=  
info=Unknown error  
infoEx=
```