

NAV-GPS MANUAL



GARMIN MONTANA 700i NAV-GPS MANUAL



GPS UNIT OVERVIEW





MAP SCREEN LAYOUT






MAP VIEW





WAYPOINT ALARM





SENDING PRESET MESSAGES





SENDING PRESET MESSAGES





ACTIVATE SOS ALARM

- 1 Lift the protective cap of the SOS button
- 2 Press and hold the SOS button
- 3 Wait for the SOS countdown

The device will send a message for medical help to Rally Control.

4 - Reply to the confirmation message

Your reply lets the Rally Control know that you are capable of interacting with them during rescue. If you do not reply, the Rally Control will still initiate a rescue.

Canceling an SOS request:

If you no longer need medical help, you can cancel the SOS request after it is sent.

- 1 Lift the protective cap and hold the SOS button
- 2 Select "Cancel SOS".
- 3 When prompted to confirm cancelation, select "Cancel SOS".

