

# SPORT TRAXX

## Sporttraxx GL320 User Guide

To send any notification to race control simply remove the unit from its bracket.

If the tracker is fixed with velcro/adhesive to the windscreen or dashboard, best is to twist and pull it.

### OK Short press

To send a OK notification: press and hold the button for around 3 seconds, till a single vibration is felt.

Release the button.

The OK has been sent.

### SOS Long press

To send a SOS request, press and hold the button for around 7 seconds, after feeling the first vibration, wait until you feel a double vibration.

Release the button.

The SOS request has been sent.

### Acknowledgment

Once the race control has received your SOS request, the unit will vibrate 5 times.

**Important:** if you did not receive the 5 vibrations after your long press for SOS, please repeat the action and eventually change (if possible) your location.

