



DISHWASHING MACHINE DETERGENT

DESCRIPTION

DISHWASHING MACHINE DETERGENT chews up grime without chewing up profits. It is a cost-effective way to get clean dishes.

Use new chlorinated **DISHWASHING MACHINE DETERGENT** liquid detergent in your dishwasher.

But even though **DISHWASHING MACHINE DETERGENT** is a hard, efficient worker, its wages are surprisingly low - the perfect kitchen helper.

APPLICATIONS & USAGE

Automatically dispense direct from shipping container to the wash tank of your dishwashing machine through electronic control dispensing equipment.

Control equipment is installed and preset at 2-5 grams/litres to remove the most stubborn and tenacious of food soils.

To maintain good results make sure wash temperature remains at 60°C. Rinse temperature at 82°F.

INDUSTRIES

1. Restaurants
2. Food Centres
3. Hotels
4. Offices
5. Hospitals

TECHNICAL SPECIFICATION

Appearance	: A clear, pale-yellow liquid
Boiling Range	: Approx. 110 degree C
Melting Range	: < 0 degree C
Specific Gravity	: 1.282 +/- 0.005 at 20°C
Flash Point	: Non - Flammable
pH	: As received 13-14 1% soln 12-13
Form	: Liquid
Vapour Pressure	: 18 mm Hg at 20 °C

PRECAUTION

Use with special care and attention. Avoid contact with skin and eyes. Before using **DISHWASHING MACHINE DETERGENT**, always read precaution and handling procedures as prescribed on container label.

KEEP OUT OF REACH OF CHILDREN