




04.80.502 – Ah8 nl 0.40 115 1000

RS 326-9987




04.80.504 – Ah10 nl 0.90 230 1000


RS 327 – 0016



04.50.504 – Ah5 nl 0.20 50 1000


RS 326-9909





04.50.508 – Ah5 nl 0.15 32 1000

RS 3269858



04.80.501 – Ah8 nl 0.40 75 1000

RS 3269965

04.80.532 – Ah10 nl 0.60 150 1000

RS 327-0000

