

Thank you for choosing **Schneider Electric** AvatarOn series products. To ensure proper application of our product, please read through the following information before installation and use.

This application guide applies to the following products.

(Notes: suffix _WE/WG/GH/LW/WD/ST_C5/G2 etc. mean the colors and sales areas)

Cat. No.	Description
E8331L1	16AX 250V 1 Gang 1 Way Sw
E8331L2	16AX 250V 1 Gang 2 Way Sw
E8332L1	16AX 250V 2 Gang 1 Way Sw
E8332L2	16AX 250V 2 Gang 2 Way Sw
E8333L1	16AX 250V 3 Gang 1 Way Sw
E8333L2	16AX 250V 3 Gang 2 Way Sw
E8334L1	16AX 250V 4 Gang 1 Way Sw
E8334L2	16AX 250V 4 Gang 2 Way Sw
E8331L1LED	16AX 250V 1 Gang 1 Way Sw w LED
E8331L2LED	16AX 250V 1 Gang 2 Way Sw w LED
E8332L1LED	16AX 250V 2 Gang 1 Way Sw w LED
E8332L2LED	16AX 250V 2 Gang 2 Way Sw w LED
E8333L1LED	16AX 250V 3 Gang 1 Way Sw w LED
E8333L2LED	16AX 250V 3 Gang 2 Way Sw w LED
E8334L1LED	16AX 250V 4 Gang 1 Way Sw w LED
E8334L2LED	16AX 250V 4 Gang 2 Way Sw w LED
E8331D20N	20A 250V 1 Gang 1 Way Double Pole Sw w LED
E8332D20N	20A 250V 2 Gang 1 Way Double Pole Sw w LED
E8331D32N	32A 250V 1 Gang 1 Way Double Pole Sw w LED
E8331D45N	45A 250V 1 Gang 1 Way Double Pole Sw w LED
E8331M	16AX 250V 1 Gang Intermediate Sw
E8331BPL1	10A 250V 1 Gang Bell Press Sw
E8332C	10A 2G Mechanical Curtain Sw
E8331PRL1	4A 250V 1G Momentary Sw
E8332PRL1	4A 250V 2G Momentary Sw
E8333PRL1	4A 250V 3G Momentary Sw
E8331	1G Sw Cover
E8331KH	1G Sw Cover w Keyholder
E8332	2G Sw Cover
E8333	3G Sw Cover
E8333KH	3G Sw Cover w Keyholder
E8334	4G Sw Cover
E8331P	1G Sw DIY Cover
E8332P	2G Sw DIY Cover
E8333P	3G Sw DIY Cover
E8334P	4G Sw DIY Cover

QGH8009313 V02




SPECIFICATIONS

Voltage	: 250V~	Current	: 4A/10A/16AX/20A/32A/45A
Mounting centre	: 60.3mm	Compliance	: IEC 60669-1, BS EN 60669-1
Self-ballast light	: 250W		MSIEC 60669-1, SS 227-1 (Cover: BS5733, IEC60670)


IMPORTANT NOTE

1. The products must be installed by qualified electricians.
2. Please check your local wiring regulations before installation.
3. Please use the standard 86 size wallbox.
4. Safekeeping the cover to prevent damage during product installation.
5. Turn off the power supply when you clean the product. Use a piece of soft, slightly-moistened cloth or tissue paper to wipe off the dust and dirt on the surface. Avoid using corrosive chemicals.


WIRING DIAGRAMS




Bell Press Switch




1 Gang 1Way Double Pole Switch



Momentary Switch



Curtain Switch



MOUNTING INSTRUCTION

1. Remove the blister cover & product cover and safekeeping.
2. Connect the wires to the terminals (recommend to leave 10-12mm bare metal wire) and tighten the terminal screws.
3. Screw the grid plate onto the wall box.
4. Snap the product cover.
5. Snap the blister cover.

