


Datasheet

End Plate End Plate, Series: 2001.2

RS Stock Number: 872-4726



Description

The AP end plates are normally used at the end of a row of terminals. If different terminals are being used within the same terminal block, then you should insert end plates in order to ensure that the touch-safe protection is maintained. The outer dimensions of the end plates match the dimensions of the terminals. Coloured end plates are used quite often in order to establish a clear visual separation between the different circuits or voltage levels. In addition, the use of end plates increases the clearance and creepage distances, which in turn influence the voltage ratings. The locking pegs ensure that the end plates can be mounted quickly. Because of the special design of the RK series, an end plate does not need to be used to separate neighbouring QI cross-connectors of different potentials.

Specifications

Colour: Beige
Width: 1.5mm
Material: PA 6.6 V2

Series overview and accessories:

Terminal blocks colour	RS Article
beige 10mm ²	762-2521
blue 10mm ²	762-2525

Accessories	RS Article
End plate AP	872-4726
Partition plate TW	501-746
Insulating cap SQIK for cross-connector	872-4739
Insulated cross-connection SQI 2 pole	762-2587
Insulated cross-connection SQI 3 pole	872-4773
Insulated cross-connection SQI 5 pole	762-2590
Insulated cross-connection SQI 10 pole	762-2593

Note: Cross connectors can be used overlapping

Fitting DIN Rails	RS Article
35mm Din Rail, slotted, 500mm	467-406
35mm Din Rail, slotted, 1000mm	467-416
35mm Din Rail, slotted, 2000mm	742-4138
35mm Din Rail, not slotted, 500mm	742-4129
35mm Din Rail, not slotted, 1000mm	467-399
35mm Din Rail, not slotted, 2000mm	467-400