


## **ELECTRONIC TIME RELAYS**

# 

RS Stock. No's. :

- 1) 896-6848 Multi-function DPCO
- 2) 896-6850 Multi-function SPCO
- 3) 896-6857 Star-Delta Starter timer

### **TERMINAL DETAILS :**



12 3.33 16 1.6


The timers shall be placed in an enclosure that is minimum 200% of the size of the timer in the end use application.

### Caution :

- Always follow instructions stated in this product leaflet.
   Before installation, check that the specifications agree with the intended application.
   Installation to be done by skilled electrician.
   Automation and control devices must be installed properly so that they are protected against any risk of involuntary actuations.
   Suitable dampers should be provided in the event of excessive vibrations.
- excessive vibrations.
- excessive vibrations.
  6. Setting of all the potentiometers should be in clockwise direction only.
  7. Do not connect supply between B1 and B2 terminals. For proper signal operation, follow supply polarity as per connection diagram.
  8. In 2AJDT0/1, any change at B1-B2 will have no effect once timer starts.
- 9. Use 250 mA fuse in series with the above mentioned
- b) So 250 that use in series with the above mentioned products.
   10. In 20NDTT & 20JDTT, use 3 A<sup>2</sup>s (1<sup>2</sup>t) fuse externally.
   11. In 20NDTT & 20JDTT, Minimum switching operational current is 10 mA.

## Product overall dimensions and

mounting details : Note : All dimensions are nsions are in 'mm'




#### Installation :

A) Base Mounting : Timer should be mounted on a plain surface.using two M4 screws. B) DIN - Rail Mounting : The Timer should be mounted on 35 mm symmetrical DIN Rail.

1) MULTI-FUNCTION DPCO Supply voltage start functions: RS Stock No: 896-6848 Timing Diagram:

#### 中 Α. 25-28 ON 15 - 18 **|** <del>-</del> Ts → DELAY 25-28 TS в. 15 - 18 INTERVAL 25-28 Ts CYCLIC 15 - 18 Ts ON/OFF D. 25-28 Ts CYCLIC 15 - 18 OFF/ON E. 25-28 1s 15-18 ONE SHOT Ts = T x t

#### **Connection Diagram :**



#### 2) MULTI-FUNCTION TIMER SPCO. Signal start functions:

Function Diagrams for 896-6850

A) SIGNAL ON DELAY :	B) ACCUMULATIVE ON DELAY:
A s <u>777777</u> 15-18 Ts	B S t 1 t 2 Ts+ t1+ t 2 Ts+ t1+ t 2
C)SIGNAL OFF DELAY :	D) SIGNAL OFF / ON DELAY:

n papa_	s <u>F77777</u>
	15-18
Ts Ts	Ts

#### E) LEADING EDGE IMPULSE 1 :

ф 🖂 🗠	<del>, , , , , ,</del>	
SETTER	p n	
	1	
-18 777	777	
'Ts '	<sup>i</sup> Ts <sup>i</sup>	' Ts '

#### a) ON DELAY :

фezz


s –

15**-**18 -


E

15

1




### Connection Diagram For 896-6850




# 3) STAR - DELTA STARTER: RS Stock No: 896-6857

When the supply is applied, Output Star Relay turns ON. After completion of set Star ON time, Star Relay turns OFF and Delta Relay turns ON after the set Pause Time and remains ON while the Supply is present.






## Connection Diagram :



#### Recommended Star - Delta Control Circuit :

( Below circuit is for STAR - DELTA Timer with 240 VAC Supply.)



- O.L.R M1 M2 M
- Mains Protection Fuse Over Load Relay First 'NO' Contact of Main Contact or Second 'NO' Contact of Main Contact or
  - Main Contact of driving Motor

  - Main Contact 'NO' Contact 'NO' Contact of Star Contact or 'NO' Contact of Star Contact or Delta Contact or 'NC' Contact of Delta Contact or

  - Star Contact of Timer (λ- Δ)
     Delta Contact of Timer (λ Δ)

#### Application :

F1 1) 2) 3) 4) 5)

5) M 6) 人C 7) 人C1 8) 人C2 9) ΔC 10)ΔC1

11) T 12) AT

Ts Ts

e) INTERVAL :

Application : For continuous process control, where a Stop resulting from a short, voltage fault could cause Serious problems. If supply interruption is < 0.2 s, then motor can be restarted immediately due to motor inertia properties. If supply interruption is within 0.2 s to 6 s (Tm settable ), then relay is made ON after set delay time (Retentive) as motor requires stabilization period. After set memory time Tm, Relay will not START until START button is pressed.

2LL017RS 00