




FC(E



Applications

- Digital Crossover
- · Bass Enhancement
- · Noise Suppression System
- · EQ Adjustment
- · Home Theatre / Car Audio

Benefits

- · Easy for Integration
- · Highly Cost-Effective

Features

- Equipped with ADAU1701 Chip
- 28/56 bit Digital Signal Processor Engine
- · 24bit ADC/DAC Resolution
- 48kHz Sample Rate
- · On-board Potentiometer for audio system control
- 5V USB Type-C Power
- Supporting SigmaStudio Programing (USBi or ICP)
- · Compact Size & Light Weight
- · Supporting 2-in, 3-out Interface Extension Board
- PCB Size: 2 x 2 inches

Overview

ADAU1701 Digital Signal Processor - SURE-APM2

The product is a digital signal processor kernel board based on ADAU1701 chip, supporting functions as gain adjustment, high-low pass filter, bass enhancement and so on. There are built-in ADC and DAC, whose dynamic range reaches 98.5dB. THD of ADC is -83dB and that of DAC is -90dB. There are four on-board potentiometers on APM2 for the gain and cut-off frequency adjustment of treble and bass. It can control the audio to the actual listening environment, speaker configurations and your music preference.

The product can supports write and download program in SigmaStudio through original USBi or ICP programmer. Taking customer's operation and real-time control requirements into consideration, it developed an APP or PC UI, with which can get the remote control of audio system (Need to connect with ICP for remote control).






It provided open-sourced demo programs of DSP products. Can download them for reference before programming. As for the correspondence of hardware and software, please refer to <The correspondence of APM2 hardware and DSP program.pdf>.

Interface Extension Board - SURE- APM2 - INT


To help customers with easy system integration, it had designed an interface extension board SURE-APM2 - INT for use with SURE-APM2, which is the same PCB size with SURE-APM2.

SURE- APM2 - INT is a 2-in, 3-out extension board, offering various input and output interfaces as RAC ports, 3.5mm jack and PH connectors. Need a 10-pin cable to connect SURE-APM2 and SURE- APM2 - INT, which comes with SURE- APM2 - INT

Diagram




ADAU1701 Digital Signal Processor - SURE-APM2




Interface Extension Board - SURE- APM2 - INT

Minimum System



Pin Definition SURE-APM2



Power Supply Connector

J2

5V USB Type-C

Audio Extension Connector

J1 PH-10pos-2mm
For connection with
SURE- APM2 - INT, the 10-pin cable
comes with SURE- APM2 - INT.

F	Pin	Definition	Pin	Definition	
	1	AINL	6	OUTL1	
	2	SGND	7	OUTR2	
	3	AINR	8	OUTL2	
	4	+3.3V	9	GND	
	5	OUTR1	10	VIN	

Dimensions: Inches (Millimetres)





Programming Connector


J11 PH-6pos-2mm

For connection with ICP programmer for programming or remote control, the 6-pin cable comes with ICP

Pin	Definition		
1	SDA		
2	SCL		
3	WP		
4	GND		
5	+5V		
6	RESET		

Extension Port


J3



Pin	Definition	Pin	Definition		
AD0	Analog Audio Input 0	GND	Ground		
AD1	Analog Audio Input 1	GND	Ground		
SCL	I2C Clock	WB	EEPROM Write Back		
SDA	I2C Data	WP	EEPROM Write Protection		
RST	Reset (Active Low)	DAC0	Digital-to-Analog Converter 0		
MP2	Multiple-Purpose Input & Output Pin, on	DAC1	Digital-to-Analog Converter 1		
MP3	APM2, these are used for potentiometer.	DAC2	Digital-to-Analog Converter 2		
MP8	(Refer to ADAU1701 data sheet for	DAC3	Digital-to-Analog Converter 3		
MP9	detailed information)	GND	Ground		
DPW	Digital Power Output	+3.3V	Power Supply (Output)		

Extension Port


J4



Pin	Definition	Pin	Definition
VIN	Other Power In	GND	Ground
MP4		GND	Ground
MP5		GND	Ground
MP1	Multiple-Purpose Input & Output Pin	GND	Ground
MP0	(Refer to ADAU1701 data sheet for	GND	Ground
MP7	detailed information)	GND	Ground
MP6		GND	Ground
MP10		GND	Ground
MP11		GND	Ground
MCLK		GND	Ground








POT1: Bass Gain


POT2: Cut-off Frequency of Bass POT3: Cut-off Frequency of Treble

POT4: Overall Gain

The adjustment range of the reset frequency



The adjustable cut-off frequency of treble: 250Hz-2kHz




■ Adjustable Range of Lower Frequency of Bass

The adjustable lower cut-off frequency of bass: 60Hz-120Hz

The adjustable upper cut-off frequency of bass: 200Hz-400Hz

Pin Definition SURE- APM2 - INT



Audio Input Connector

J1 3.5mm AUX IN J2, J5 RCA Jack J3 PH-4pos-2mm Line Input

Pin	Definition		
1	INL		
2	GND		
3	GND		
4	INR		

Note: The three input methods cannot be used at the same time





Audio Output Connector

J7 3.5mm Headphone Output J6, J9 RCA Output J10 RCA for Subwoofer Output J8 PH-4pos-2mm Line Output

Pin	Definition			
1	INL			
2	GND			
3	GND			
4	INR			

Connection Connector

J4

Pin	Definition								
1	AINL	3	AINR	5	OUTR1	7	OUTR2	9	GND
2	AGND	4	+3.3V	6	OUTL1	8	OUTL2	10	VIN

Part Number Table

Description	Part Number
2 × In, 4 × Out Audio Digital Signal Processor Kernal Board - ADAU1701	SURE-APM2
2 × In, 3 × Out Digital Signal Processor Extension Board	SURE- APM2 - INT

Important Notice: This data sheet and its contents (the "Information") belong to the members of the AVNET group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. Multicomp Pro is the registered trademark of Premier Farnell Limited 2019.

