



Ti300U, Ti400U, Ti401U, Ti480U Thermal Imagers




To download SmartView IR software, visit www.fluke.com/smartview-ir.
要下载 SmartView IR 软件, 请访问 www.fluke.com/smartview-ir.




1 ⓘ




2a AF




2b MF




3






4



5





1 Bluetooth®

F2 > Settings > Connection > Bluetooth(on) > Headset



2 [Microphone icon] / [Text icon]

F2 > Gallery > Edit > Edit >

Voice Annotation / Text Annotation

Menu

Scale mode	ROI	Parameters	Auto	38.6
Palettes	Text Annotation	Voice Annotation		
File Property	2022-12-29	FLUKE		
Confirm	Cancel			12.8



2a F

SmartView IR

IR Camera Workspace

2b

Devices and drives (5)

Fluke Ti480u#L25

SD Card

28.8 GB free of 28.8 GB