

Thank you for choosing **Schneider Electric** Affle Plus switches. To ensure proper application of our product, please read through the following information before installation and use.

This application guide applies to the following products.

Cat. No.	Description
A3G15	13A Single Gang Switched Socket
A3G426	13A Single Gang Socket
A3GT25	13A Twin Gang Switched Socket
A3GT426	13A Twin Gang Socket
A3G15_15	15A 250V 1 Gang 3 Round Pin Switched Socket
A3G426_15	15A 250V 1 Gang 3 Round Pin Socket


SPECIFICATIONS

Voltage	: 250V~
Mounting centre	: 60.3mm
Current	: 13A/15A
Compliance(13A)	: BS1363-2,MS589
Compliance(15A)	: BS546,MS1577

IMPORTANT NOTE



1. The products must be installed by qualified electricians.
2. Please check your local wiring regulations before installation.
3. Safekeeping the surround to prevent damage during product installation.
4. Turn off the power supply when you clean the product. Use a soft, slightly-moistened cloth or tissue paper to wipe off the dust and dirt on the surface. Clean with much diluted detergent if necessary but avoid using corrosive chemicals.

WIRING DIAGRAMS



MOUNTING INSTRUCTION

1. Connect the wires to the terminals (recommend to leave 10-12mm bare metal wire) and tighten the terminal screws.
2. Screw the grid plate onto the wall box.
3. Snap the surround.



Insert a screwdriver into the clip lock, and twist the screwdriver to remove the surround and dolly .