



- Place inlet valve through inlet hole with inlet rubber washer inside the cistern
- Secure with backnut
- Connect the supply
- Adjust water level with grey adjusting screw.

N.B.: Make connecting tightness with filter seal