

| | | |
|---------------------------|---------------|---------------------------------|
| Suitable Terminals for RS | 501796 | |
| | | |
| | RS Part No | Description |
| | 501843 | Fuseholder feedthrough terminal |