



905-8770

Air Purge Collar for Infrared Temperature Sensor


Helps keep the lens of the sensor clean and dry

Requires a continuous supply of clean air

SPECIFICATIONS

Construction	Anodised aluminium (air fitting: nickel plated brass)
Weight	25 g
Air fitting	Hose barb (diameter 5 mm)

INSTALLATION & DIMENSIONS



Connect a continuous supply of clean ("instrument") air to the inlet. High pressure is not recommended. Use only enough air to provide a positive pressure in front of the lens of the sensor.

Check the lens periodically to ensure it is clean and dry.

ALSO AVAILABLE



Mounting bracket
(RS Stock No. 905-8777)