



WingSpan Wall Stand Off Instructions


**Little
Giant**
Ladder Systems



1. Place arm into the rung bracket while pushing in on the locking pin. Slide arm into bracket until the locking pin engages in to the hole.




2. Repeat the first instructions for the second arm.




3. Place the WingSpan on the top rung of the ladder when the ladder is in extension position only. Make sure the WingSpan is centered securely on the top



4. Swing the clamp into the front slot of the bracket so that the clamp is facing downwards. An adjustment of the clamp maybe necessary to insert clamp into the front slot.



5. This is how the WingSpan should look after you have assembled it.



A. Rung Bracket

B. Arm Assembly Including Feet(2)

C. Rubber Foot (2)

Part No.

53196

21093

51243

Little Giant Ladder Systems Toll Free: 800-453-1192
1198 N. Spring Creek Place Phone: 801-489-3684
Springville, UT 84663 Fax: 801-489-3685

www.littlegiantladders.com
©2010 Little Giant Ladder Systems PN: 51246 V3

LITTLE GIANT® LADDER SYSTEMS

WINGSPAN WALL STAND OFF WARRANTY

Little Giant Ladder Systems warranties each new WingSpan Wall Stand Off, to original purchaser thereof, to be free from defects in workmanship and materials when operated under normal conditions and maintained properly. This warranty covers all parts of the WingSpan Wall Stand Off.

This warranty shall be in effect for a period of 1 year from the date of purchase. This shall be in lieu of any other warranty, expressed or implied, including, but not limited to, any implied warranty of merchantability or fitness for a particular purpose. Certain states do not allow limitations on how long an implied warranty lasts. The above limitation may not apply to you.

Little Giant Ladder Systems will repair or replace, at its option and without cost to the original purchaser, any WingSpan Wall Stand Off which has been found defective and is within the period of warranty. All freight to and from factory is to be paid by the customer. The factory address is: Little Giant Ladder Systems, 1198 North Spring Creek Place, Springville Utah 84663.

The liability of Little Giant Ladder Systems under this warranty shall be limited solely to repair or replacement of the WingSpan Wall Stand Off within the warranty period; Little Giant Ladder Systems shall not be liable, under any circumstances, for consequential or incidental damages, including, but not limited to, personal injury or labor costs. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives the original purchaser specific legal rights and you may have other rights which vary from state to state.

Under no circumstances will Little Giant Ladder Systems be responsible for any expense in connection with any repairs made by anyone other than the factory or authorized service station unless such repairs have been specifically authorized in writing by Little Giant Ladder Systems.