



BINOCULAR MAGNIFIER



**A PRECISION INSTRUMENT
THAT IMPROVES VISION AND
INCREASES YOUR EFFICIENCY**

HOW TO CARE FOR THE OPTIVISOR

The OptiVISOR lenses are ground and polished to precision ophthalmic standards. They are made of optical glass of the highest quality obtainable. The lenses should be kept clean by wiping them with a clean soft cloth or lens-wiping tissue or they may be washed in soap and water. Caution should be used to avoid rubbing or hitting them against hard abrasive surfaces. The body of the OptiVISOR may be cleaned with soap or detergent without effect. Avoid hard chemicals or solvents which may attack or stain the surface.

FOCAL DISTANCE OF THE OPTIVISOR

The optical components of the OptiVISOR consists of equally ground prismatic lenses which assist the eyes to converge at a given focal distance. This focal distance depends on the power of the particular lens plate being used in the instrument. Each lens plate is marked with the diopter power of the lenses it carries. The following list designates the approximate focal length of the various lens plates.

Lens Plate No.	Magnifies	Focal Length
2	1½ times	20 inches
3	1¼ times	14 inches
4	2 times	10 inches
5	2½ times	8 inches
7	2¾ times	6 inches
10	3½ times	4 inches

All of the above listed lens plates are interchangeable on the OptiVISOR and are available from parts list.

HOW TO ADJUST THE OPTIVISOR

The OptiVISOR is made of lightweight, durable impact resistant material. The design is such that when properly adjusted it should cause no discomfort when worn for long periods of time.

The model DA continuous headband may be adjusted to fit the head by turning the knurled knob at the rear clockwise to make smaller or counter-clockwise for larger. Only enough tension is necessary to hold the band in place when the visor is raised or lowered.

The adjustable pivot assembly on either side of the visor should tighten to hold the visor in any position it is placed. If at any time the tension nut is backed off too far or disassembled, make certain that the square on the bearing plate fits the square on the tension screw when re-tightening.

The OptiVISOR should be worn square on the head with the lens divider centered before the bridge of the nose.

NOT A SAFETY DEVICE. DO NOT USE IN PLACE OF SAFETY GLASSES OR FACE SHIELD

DISTRIBUTED
BY



SHESTO LTD
UNIT 2
SAPCOTE TRADING CENTRE
374 HIGH ROAD
WILLESDEN
LONDON NW10 2DH
ENGLAND
Tel: 020 8451 6188
Fax: 020 8451 5450

OptiVISOR
Optical Glass Binocular Magnifier



Model DA

OptiLOUPE

**Tools, Supplies
and Equipment**
for Technicians and Craftsmen

DISTRIBUTED
BY

SHESTO

SHESTO LTD

UNIT 2

SAPCOTE TRADING CENTRE

374 HIGH ROAD

WILLESDEN

LONDON NW10 2DH

ENGLAND

Tel: 020 8451 6188

Fax: 020 8451 5450