


Piston ring compressor - 2205



Description

- use to install pistons on most passenger cars.
- high quality construction with sprung steel wraps
- with safety adjusting screws
- available in a wide range of sizes
- This tool is used to install pistons and piston rings into engine cylinders. Different sizes are available.

How to use the tool:

- Insert the piston and any piston rings into the tool, position the tool at the opening and use it to insert/push the piston and any piston rings into the cylinder.

Technical Data

Barcode	H	Dx	Dx	Person icon	Box icon	Wrench icon	
619725	50	1 3/4" - 3 1/2"	40 - 90	178	1G	1	-
619726	80	2 1/4" - 5"	57 - 125	291	1G	1	-
619727	80	3 1/2" - 7"	90 - 175	320	1G	1	-
619729	165	3 1/2" - 7"	90 - 175	587	1G	1	-

Packaging data

Barcode	H	Retail tool packaging				Transport package				
		Retail packaging in mm (length)	Retail packaging in mm (width)	Retail packaging in mm (height)	Person icon	Hand icon	Transport packaging in mm (length)	Transport packaging in mm (width)	Transport packaging in mm (height)	Person icon
619725	50	90	112	58	248	1	90	112	58	248
619726	80	107	120	93	361	1	107	120	93	361
619727	80	107	123	92	390	1	107	123	92	390
619729	165	120	170	100	657	1	120	170	100	657